

SPECTRUMSMT.COM
info@spectrumsmt.com



Call USA: +1 (855) 261 1805
Call UK: +44 0844 556 1203

US • UK • EU

SMT MACHINE SPARES

Juki SMT Machine Spares

Part numbers and descriptions

Working with our partners worldwide we have access to a large inventory of original machine spares for both current and older machines. In many cases we have stock of obsolete parts for machines no longer supported by the manufacturer. For your convenience we have listed, in an easy to read format, the spares offered by the manufacturers. We also repair and exchange many spares parts.

If you cannot locate what you need from your main dealer or you are interested in making some savings then please feel free to contact us for a quote and availability.

YOUR PERFECT SMT PARTNER

Juki SMT Machine Spares

Cyberoptics Laser 6604054	CPU Board E86087290B0	Timing BELT E2107729000	Detector X E9609725000
SAFETY BOARD B ASM E86017290B0	Valve E93188020A0	Rubber RING E2151723000	Msm CARD E9609729000
SASE-FEEDER BOARD ASM E86027290C0	Sensor ASM E93208550A0	Air CYLINDER E2254802000	Laser BOARD E9610729000
LIGHT CTRL BOARD AB ASM E8603729AB0	Parallel CABLE E93237290A0	Belt E2306725000	Laser E9611729000
I/O CTRL PWB ASM E86077290C0	Trunk CABLE E93287210A0	Timing BELT E2308725000	Driver E9612721000
IMG-CUP BOARD B ASM E86087290B0	Cable ASM E93367210A0	Bearer ASM E2330725000	Photo INTERRAPTER E9613717000
IP-X BOARD B ASM E8603729AB0	Cable E93367250A0	Rail ASSY E2331715000	Motor E9624729000
BUS BRIDGE BOARD E9603729000	Cable E93407250A0	Timing BELT E2432725000	Board E9626729000
XMP(MAIN) E9606729000	Sensor E93587150A0	Belt E3014729000	Motor E9629729000
XMP(4SE/4ST) E9607729000	Sensor E94647250A0	Belt Z E3021729000	Land ASM E9630721000
MCM(4 SHAFT) E9609729000	Board E96567290A0	Timing BELT E3023725000	Motor E9630729000
UPS E9659729000	Tang CHAIN E205572900	Nozzle HOLDER E3051729000	Laser E9631721000
XY 4 SHAFT DRIVER E9620729000	Timing BELT E323725000	Filter E3052729000	Servo MOTOR E9631729000
YC 1 SHAFT DRIVER E9621729000	Chain TABLE E873572000	Valve E3066700000	Driver E9635721000
DRIVER E9626729000	Ball SLIDE 1045 E1107717000	Shaft IC E3141729000	Laser E9635725000
STEP DRIVER HX004200000	Spring A E1480729000	Filter element E3273729000	Hod ASM E9649729000
MAGNESCALE DETECTOR E9641729000	Belt E2004729000	E NOZZLE E3571721000	Driver EE085U001
SENSOR HEAD (X8M) E9641729B00	Belt YBE E2009729000	Calibration jigs E3622721000	Ejector valve 40010678
SENSOR HEAD (Y8M) E9641729C00	Belt C E2016725000	Linear WAY E4211717000	FILTER 4000200
CPU BOARD ASM E96567290A0	Belt S E2017725000	Conveyor BELT E4256729000	FILTER 4000300
MOTOR DRIVER HX005450000	Rail ASM E2055729000	Conveyor BELT E4257729000	0.4 VCS LIGHT PWB ASM E86157210A0
	Rail ASM E2058729000	Chain CABLE E8736725000	

Juki SMT Machine Spares

2-Lane Belt Feeder, SOW (2 SOWIC) MBF44-SOW	BEARING NO. 41 SB112000600	Cyberoptics Board PWA5120075	FOCUS MODULAR LA UNIT E9635725000
2-Lane Belt Feeder, SOY (2 SOYIC) MBF44-SOY	BOC CAMERA CABLE ASM E94587150A0	Cyberoptics Board PWA8002763	Focused Modular E9635721000
3-Lane Belt Feeder, 2 .300", 1 .400", SOJ (2x.3" SOJ + 1 .4" SOJ) MBF44-SOJ	BU DOWN SENSOR E94697250A0	DC SERVO CONTROL PWB ASM E86037210A0	FX-1/R ZT SERVO AMP L901E521000
AC SERVO CONTROL PWB ASM E86027210A0	BU UP SENSOR E94687250A0	DEFRIX OIL No1 MDFRX1001LO	Gantry drive motor Juki KE2050-L, x-axis (Tamagawa Seiki TS) 4613N1020E200
AC SERVO CONTROL PWB ASM E8602721AA0	C OUT SENSOR CABLE ASM E93637210A0	DEFRIX OIL No2 MDFRX2001LO	GAS SPRING 730-760 CE E5154715000
AC SERVO DRIVER E9612721000	CAM FOLLOWER RETURN SPRING E1327706000	DOOR PIVOT BLOCK E4504717000	GREASE MGREAS400G0
AC SERVO DRIVER 30W KM000000060	CARRY PWB A E86177210A0	DOS FORMAT HDD ASM 40010251	HAND VALVE PV010006000
AC SERVO MOTOR E9611721000	CARRY PWB ASM E86067210A0	DOS FORMAT SDD 128MB 40031401	HARD DISC ASM JE 40002937
AIR COMBINATION PF0552120A0	CE OPERATION PWB ASM E8605721AA0	DRIVE BELT E2051721000	HEAD 1 VACUUM ON CABLE ASM E93147210A0
AIR CYLINDER PA0601011A0	CHIP BOX ASM. E28017210A0	DUMPER SCREW E3520721000	HEAD 3 VACUUM ON CABLE E93207250A0
ARCNET PCB FOR ISA BUS E8651715AA0	CIRCUIT PROTECTOR 10A HA00380000B	EJECTOR VBH 07 E3066700000	HEAD ENCODER RELAY CABLE ASM E93367250A0
ARCNET PWB ASM FOR ISA BUS E86117210A0	CONNECTOR FOR STICK FEEDER E95537160A0	F EMERGENCY SW CABLE ASM. E94107250A0	HEAD MAIN PWB ASM E86077210A0
ATC BASE E3453721000	CONVEYOR BELT E2056721000	Feeder Bank Trunk Cable E93877210A0	HEAD MOTOR PWB ASM E86147210A0
ATC UNIT ASM (730) E34017210A0	CONVEYOR BELT E2216725000	FEEDER UNIT PWB ASM E86147150A0	HEAD PRESSURE SENSOR CABLE ASM E93157210A0
ATC-ANGLE E3411715000	CONVEYOR BELT E2217725000	FILTER (dia. 4.8mm id 2.9mm h 17.0mm) E3052729000	HEAD UP SP E3026725000
READER E32907210A0	CONVEYOR BELT C (730/740 3 MOTOR) E2188721000	FILTER (dia. 5.0mm id 2.0mm h 23.5mm) 40046646	HOD BOX CE VERSION E1700721A00
BALL SCREW E3024721000	CONVEYOR BELT S E2017725000	FILTER ELEMENT VFL44 FILTER ELEMENT A PF901002000	I/O CONTROL PWB ASM E86047210A0
BASE UNIT PWB ASM E86167210A0	CONVEYOR BELT S (730/740 3 MOTOR) E2189721000	FILTER ELEMENT B PF901003000	Intelligent 12mm Tape Feeder RF-Type (for RS-1) RF12AS
BEARING FOR YA PULLEY BRACKET B3406180000	COUPLING FM740 E3023721000	FIXING PLATE B E2607721000	Intelligent 16mm Tape Feeder RF-Type (for RS-1) RF16AS
	COVER FUR (CE) E1130725000	Floating Joint E240676000	

Juki SMT Machine Spares

Intelligent 24mm Tape Feeder RF-Type (for RS-1) 40175380 RF24AS	LASER SENSOR FS730 6604054	NOZZLE SLIDER 1 E3521721000	RAIL SUPPORT E2129729000B
Intelligent 32mm Tape Feeder RF-Type (for RS-1) RF32AS	LIMIT SENSOR HD000350000	NOZZLE SLIDER 103 E3523721000	RAIL SUPPORT C E2330729000A
Intelligent 44mm Tape Feeder RF-Type (for RS-1) RF44AS	LINEAR GUIDE E3022721000	NOZZLE SLIDER 104 E3524721000	RAIL SUPPORT SHEET E2164729A00A
Intelligent 56mm Tape Feeder RF-Type (for RS-1) RF56AS	MAGNET SCALE HEAD E9608721000	NOZZLE SLIDER No 106 E3001705000	RAIL SUPPORT SHEET E2164729C00B
Intelligent 8mm Tape Feeder RF-Type (for RS-1) RF08AS	MAGNETSCALE DETECTOR X-AXIS E9609725000	Nozzle Tip(Slider) Only (# 101 to # 106) E352X721000	RAIL SUPPORT SHEET L 40008097
Juki NOZZLE 201 dia. 3,5x1,5 E35517210A0	MC5M10HSV8S24B Ejector 70 ASM KE2070/2080 40050034 MC5M10HSV8S24B Z1	OCC LIGHT PWB ASM E86127210A0	RAIL SUPPORT U 40008095
Juki NOZZLE 202 dia. 5,5x3,2 E35527210A0	Ejector ASM KE2070/2080 40045471	OCC RELAY CABLE ASM. E94527210A0	REEL COLLAR 24mm PINK E6522705000
Juki nozzle 500 Tip/Slider w/rubber pad 400-11046-T	MCMR, Four Channel, V 1.8 E9609729000A	OPERATION PWB ASM E86057210A0	REEL COLLAR 8 NF08NS E6378705000
JUKI NOZZLE 503 TIP/SLIDER. \pm 1.0 / \pm 0.6 400-01341-T	Mini Decompression Valve PC0205010A0	OUT SENSOR CABLE E94677250A0	RELAY HB000630000
JUKI NOZZLE 504 TIP/SLIDER. \pm 1.6 / \pm 1.0 400-01342-T	MNLA E9611729000	OUT SENSOR CABLE ASM E93617210A0	ROTARY BLOCK ASSEMBLY E30107210A0
JUKI NOZZLE 505 ASSY 40001343	MOTOR, THETA E93067210A0	PHOTO INTERRUPTOR HD000670000	SAFETY COVER STOPPER E1348700000
JUKI NOZZLE 505 TIP/SLIDER. \pm 3.5 / \pm 1.7 400-01343-T	NOZZLE 500 TIP 1.0 X 0.5 (1005/1608) E365X729000 NOZZLE ASM 103 E35037210A0	Power cable (6.2m) E94507000A0	Screw SM8060502TP
JUKI NOZZLE 506 TIP/SLIDER. \pm 5.0 / \pm 3.2 400-01344-T	Nozzle ASM for 0201 E35017250A0	POWER SUPPLY (12V/4.2A) HX004230000	SCREW SUPPORT E3004721000
Keyboard Bracket E13097290A0	NOZZLE ASSEMBLY 514 E36197290A0	POWER SUPPLY (24V/10A) HX003240000	SENSOR MAGNET SWITCH E9607715B00
LAHD CYBEROPTIC ASM. E9630721000	Nozzle Assy, # 102-Melf E3502721MELF	POWER SUPPLY (6V/4A) HX004220000	SERVO MOTOR 30W Z AXIS 40044534
LAHD Z1 MOTOR ASM E93077210A0	NOZZLE INNER 101 E3511721000	POWER SUPPLY 5V 30A (730/740) HX004420000	SET COLLAR E3027721000
LAIC HEAD Z AXIS MOTOR ASM E93037210A0	NOZZLE OUTER GUIDE E3030721000	PROTECTOR 15A HA00380000C	SIGNAL TOWER (LIGHT BULB) E9690715000
	NOZZLE PIN E3074700000	PULLEY XA 730/740 E2410721000	Stick feeder Lane No. 1-2, Comp.Types PLCC28/32, Lane Width .506" MBF44-PLCC28/32
	NOZZLE PIN E3075700000	PWB INNER E2021721000	Stick feeder Lane No.1, Comp.Types PLCC68, Lane Width 1.006" MBF44-PLCC68
		R BANK UP DETECT CABLE ASM E95587210A0	

Juki SMT Machine Spares

Stick feeder Lane No.1, Comp.Types PLCC84, Lane Width 1.206" MBF44-PLCC84	Tape feeder 8mm, Pitch (4), 15" reel NF-8L1E	Tape Feeder CTF 8mm paper, Pitch 4mm, large reel CF8L1P	Tape Feeder FTF 8mm, Pitch 4mm, 7" reel FF081E
Stick feeder Lane No.1- 2, Comp.Typ.SOIC8- 16 u.PLCC52, Lane Width.251" - .806" MBF44-PLCC52/SOIC	Tape feeder 8mm, Pitch adjustable (2/4), 15" reel NF-8LN	Tape Feeder CTFR 8mm Pitch 4mm CF8L1ER	Tape Feeder FTFR 32mm (Deep Pocket) FF32FR-OP
Stick feeder Lane No.1- 2,Comp.Typ.SOL16- 28 u.PLCC44, Lane Width.432" - .706" MBF44-PLCC44/SOL	Tape feeder 8mm, Pitch adjustable (2/4), 7" reel NF-08N	Tape Feeder for 01005 1.115 AQ02HP	Tape Feeder FTFR 44mm (Deep Pocket) FF44FR-OP
Stick feeder Lane No.1- 2,Comp.Typ.SOL16- 28 u.PLCC44, Lane Width.432" - .706" MBF44-PLCC44/SOL	Tape Feeder ATF 16mm Deep Pocket 18mm Pocket Depth AF16FS-DP	Tape Feeder FTF 12mm standard, Pitch 4 - 12mm, 15" reel FF12FS	Tape Feeder FTFR 56mm FF56FR-OP
Stick feeder Lane No.1- 2,Comp.Types PLCC20, Lane Width .404" MBF44-PLCC20	Tape Feeder ATF 24mm (Deep Pocket) AF24FS-OP	Tape Feeder FTF 16mm standard, Pitch 4 - 12mm, 15" reel FF16FS	TAPE HOLDER 12 ASM E33107060A0A
Stick feeder Lane No.1- 2,Comp.Types SOL16-28, Lane Width .432" MBF44-SOL	Tape Feeder ATF 24mm, 15" reel holder AF24FS	Tape Feeder FTF 24mm standard, Pitch 8 - 24mm, 15" reel FF24FS	THETA COUPLING E3025725000
Stick feeder Lane No.1-4, Comp.Types SOIC 8-16, Lane Width .251" MBF44-SOIC	Tape Feeder ATF 8mm paper (splicing) 0402 (1005), Pitch 2mm, 7" reel AF05HP	Tape Feeder FTF 32mm standard, Pitch 12 - 32mm, 15" reel FF32FS	THETA PULLEY E3011721000
SWING PLATE ASM E11067060A0A	Tape Feeder CTF 8mm embossed, Pitch 2mm, 7" reel CF08HE	Tape Feeder FTF 44mm standard, Pitch 12 - 44mm, 15" reel FF44FS	UNION FILTER PF010001000
T BELT TENSIONER E3012721000	Tape Feeder CTF 8mm embossed, Pitch 4mm, 7" reel CF081E	Tape Feeder FTF 44mm, deep pocket, pocket depth 25mm FF44DP	UPPER COVER 1212 ASM E32037060AC
Tape feeder 12mm, Pitch adjustable (4/8/12) NF-12	Tape Feeder CTF 8mm embossed, Pitch 4mm, 7" reel CF081ER	Tape Feeder FTF 56mm standard, Pitch 12 - 16mm, 15" reel FF564S	UPPER COVER ASM for CF081E CF8L1E FF081E and FF8L1E E2203706CA0
Tape feeder 12mm, Pitch adjustable (4/8/12) NF-12NS	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel CF08L1ER	Tape Feeder FTF 8mm paper (0402) FF08HE	Vacuum Filter RX-7 40163249
Tape feeder 16mm, Pitch adjustable (4/8/12) NF-16	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel CF8L1E	Tape Feeder FTF 8mm, Pitch 4mm, 15" reel FF8L1E	VDS Display Monitor MIC- N952V-JK E94557150A0
Tape feeder 16mm, Pitch adjustable (4/8/12) NF-16NS	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel CF8L1E		VDS Display Monitor MJ- 971Y7-JK 12V 39.591.023
Tape feeder 24mm, Pitch adjustable (4/6/8/10) NF-24	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel CF8L1E		WAIT SENSOR CABLE A E94647250A0
Tape feeder 24mm, Pitch adjustable (6/8/10/12) NF-24FS	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel CF8L1E		X AXIS CABLE BARE E2429715000
Tape feeder 8mm Pitch (4), 7" reel NF-081E	Tape Feeder CTF 8mm for 0201 and 0402 for 7" Reel CF03HPR		X AXIS PLASTIC RAIL ASM 20 with edge plates 40008068
	Tape Feeder CTF 8mm paper 0402 (1005), Pitch 2mm, 7" reel CF05HP		X AXIS PLASTIC RAIL CHAIN 40 (21 links) 40008069
			X AXIS PLASTIC RAIL LINK 40 40008065

Juki SMT Machine Spares

XY 4 SHAFT DRIVER(X SHAFT) E9620729C00	RATCHET HOOK STOPPER 40081799	UPPER COVER 1612ASM. E4203706AACA	OUT PUT GUIDE E7402706000
XY 4 SHAFT DRIVER(Y SHAFT) E9620729D00	REEL SUPPORT ARM ASM. E1610706AA0	UPPER COVER 2424ASM. E5203706AAE	Pressure roller asm (ATF8mm) E1321-706-AA0
Y - AXIS CABLE BEARER E2331715000	SHAFT E1314706A00	UPPER COVER ASM(3). E1202-706-CA0	REEL HOUSING ASM E1304-706-0B0
Y AXIS PLASTIC RAIL (40) E2058729000	SHAKE ARM (CTFR) 40081807	UPPER COVER ASM(5). E1203-706-CA0	REEL SHAFT E3306-706-000
YA PULLEY BRACKET ASM E23077210A0	SHAKE ARM 4MM ASM 40081827	UPPER COVER HOOK E1211-706-C00-A	REEL SHAFT E3306-706-000 JM
Y-AXIS PLASTIC RAIL ASM (40) (only plastic rail) E2057729000	SHAKE ARM ASM E1303-706-0A0	UPPER COVER SHAFT E1209-706-000	REEL SHAFT (CTF) E1307-706-C00
Y-AXIS PLASTIC RAIL ASM 20 (2010/2020 L) 40017719	SHAKE ARM ASM) E1303706AC0	UPPER COVER SHAFT (CTF) E1209-706-C00	REEL SHAFT 32R 1 E6666706R00
Z SLIDE BRACKET E3007721000	SLIDE PLATE (ATF8mm) E1115-706-A00	WHEEL ASM (Sprocket) E1102-706-0A0	SHAKE ARM ASM E1303-706-0A0
Z SLIDER SHAFT E3008721000	STOPPER CLICK 40081800	WHEEL BUSH SPACER 03 E1108706C00	SHUTTER PLATE 32 ASM. E62207060A0
Z-SLIDE SHAFT A E30067250A0	STOPPER HOOK E1112-706-C0	WHEEL COLLAR 03 E1104706C00	ST PL BK 1 E6125706R00
Z-SLIDE SHAFT IC ASM E32067250A0	STOPPER HOOK E1112-706-000-A	WHEEL PLATE 03 E1130706C00	STOPPER 12/16/24-NS E313070600E
BEARING SB304000100	SWING PLATE 03 ASM.) E1106706CB0	WHEEL RING 03 E1109706C00	STOPPER 8x2) E6822-705-000
CLUTCH HOLDER ASM. E1301706AA0	SWING PLATE ASM E1106-706-0A0	X-Axis adjusting bracket asm.(CTF/ATF) E1005-706-CA0	STOPPER HOOK E1112-706-000-A
HOLDER_PLATE_ASM CTFR 40081848	TAPE HOLDER ASM. E1310706CA0	X-AXIS POSITIONGING PIN E1002-706-000	SUTTER PLATE 32 ASM. 1 E6220706AA0
HOLDER_SH CTFR 40081849	TAPE HOLDER PLATE E1321706C00	12/16/24MM FEEDER E3292-760-000	SWING PLATE ASM E3106-706-0A0
HOUSING ASM E1304-706-CA0	TAPE HOLDER_ASM (CTFR) 40081851	BEARING SB304000100	SWING PLATE ASM. E61067060A0
KNOCK LEVER LINK ASM. E1115706AB0	UP CV 08 ASM CTFR 40081845	LINK 24ASM E5115-706-0B0	TAPE HOLDER ASM (CTF) E1310-706-CA0
KNOCK LEVER LINK ASM. E1115706CB0	UP CV HOOK ASM 40081910	LINK 24ASM (FF24mm) E5115-706-0B0	TAPE HOLDER ASM. E1310-706-0A0
LINK 12 ASM. E3115706AB0	UPPER COVER 05 ASM (ATF) E1201-706-AA0	LINK ASM E3115-706-0B0	TAPE HOLDER ASM. E6310-706-0A0-A
PRESSURE ROLLER (ATF) E1321706A00	UPPER COVER 08ASM E1202-706-AA0	LINK ASM. E11157060B0	TAPE HOLDER ASM. E3310-706-0A0
	UPPER COVER 1212 ASM. E3203706AACA	LOCK HOLDER SCREW E1523-706-C00	TAPE HOLDER ASM. (FTF44mmmm) E7310-706-0A0-A
			UPPER COVER 08 ASM. E2203-706-CA0

Juki SMT Machine Spares

UPPER COVER 1204 ASM E3203-706-0AA	YC 1 SHAFT DRIVER E9621729000	Ball SLIDE 1045 E1107717000	Shaft IC E3141729000
UPPER COVER 1208 ASM E3203-706-0AB	DRIVER E9626729000	Spring A E1480729000	Filter element E3273729000
UPPER COVER 1212 ASM E3203-706-0AC	STEP DRIVER HX004200000	Belt E2004729000	E NOZZLE E3571721000
UPPER COVER 1604 ASM E4203-706-0AA	MAGNESCALE DETECTOR E9641729000	Belt YBE E2009729000	Calibration jigs E3622721000
UPPER COVER 1608 ASM (2) E4203-706-0AB	SENSOR HEAD (X8M) E9641729B00	Belt C E2016725000	Linear WAY E4211717000
UPPER COVER 1612 ASM E4203-706-0AC	SENSOR HEAD (Y8M) E9641729C00	Belt S E2017725000	Conveyor BELT E4256729000
UPPER COVER 2408 ASM E5203-706-00A	CPU BOARD ASM E96567290A0	Rail ASM E2055729000	Conveyor BELT E4257729000
UPPER COVER 2412 ASM (3). E5203-706-0AB	MOTOR DRIVER HX005450000	Rail ASM E2058729000	Chain CABLE E8736725000
UPPER COVER 2416 ASM E5203-706-0AC	CPU Board E86087290B0	Timing BELT E2107729000	Detector X E9609725000
UPPER COVER 2424 ASM E5203-706-0AD	Valve E93188020A0	Rubber RING E2151723000	Msm CARD E9609729000
UPPER COVER 3212ST E6203706RB	Sensor ASM E93208550A0	Air CYLINDER E2254802000	Laser BOARD E9610729000
UPPER COVER 3232ASM E6203-706-0AC	Parallel CABLE E93237290A0	Belt E2306725000	Laser E9611729000
UPPER COVER 4444ASM E7203-706-0AC	Trunk CABLE E93287210A0	Timing BELT E2308725000	Driver E9612721000
UPPER COVER SHAFT E1209-706-000	Cable ASM E93367210A0	Bearer ASM E2330725000	Photo INTERRAPTER E9613717000
WHEEL ASM (Sprocket) E1102-706-0A0	Cable E93367250A0	Rail ASSY E2331715000	Motor E9624729000
X-AXIS POSITIONING PIN ASM (FTF) E1001-706-0A0-A	Cable E93407250A0	Timing BELT E2432725000	Board E9626729000
XMP(MAIN) E9606729000	Sensor E93587150A0	Belt E3014729000	Motor E9629729000
XMP(4SE/4ST) E9607729000	Sensor E94647250A0	Belt Z E3021729000	Land ASM E9630721000
MCM(4 SHAFT) E9609729000	Board E96567290A0	Timing BELT E3023725000	Motor E9630729000
UPS E9659729000	Tang CHAIN E205572900	Nozzle HOLDER E3051729000	Laser E9631721000
XY 4 SHAFT DRIVER E9620729000	Timing BELT E323725000	Filter E3052729000	Servo MOTOR E9631729000
	Chain TABLE E873572000	Valve E3066700000	Driver E9635721000

Juki SMT Machine Spares

Laser E9635725000	BEARING FOR YA PULLEY BRACKET B3406180000	Cyberoptics Board PWA8002763	FX-1/R ZT SERVO AMP L901E521000
Hod ASM E9649729000			
Driver EE085U001	BEARING NO. 41 SB112000600	DC SERVO CONTROL PWB ASM 86037210A0	Gantry drive motor Juki KE2050-L, x-axis (Tamagawa Seiki TS) 4613N1020E200
Ejector valve 40010678	BOC CAMERA CABLE ASM E94587150A0	DEFRIX OIL No1 MDFRX1001LO	
FILTER 4000200			GAS SPRING 730-760 CE E5154715000
FILTER 4000300	BU DOWN SENSOR E94697250A0	DEFRIX OIL No2 MDFRX2001LO	
0.4 VCS LIGHT PWB ASM E86157210A0	BU UP SENSOR E94687250A0	DOOR PIVOT BLOCK E4504717000	GREASE MGREAS400G0
2-Lane Belt Feeder, SOW (2 SOWIC) MBF44-SOW	C OUT SENSOR CABLE ASM E93637210A0	DOS FORMAT HDD ASM 40010251	HAND VALVE PV010006000
2-Lane Belt Feeder, SOY (2 SOYIC) MBF44-SOY	CAM FOLLOWER RETURN SPRING E1327706000	DOS FORMAT SDD 128MB 40031401	HARD DISC ASM JE 40002937
3-Lane Belt Feeder, 2 .300", 1 .400", SOJ (2x.3" SOJ + 1 .4" SOJ) MBF44-SOJ	CARRY PWB A E86177210A0	DRIVE BELT E2051721000	HEAD 1 VACUUM ON CABLE ASM E93147210A0
AC SERVO CONTROL PWB ASM E86027210A0	CARRY PWB ASM E86067210A0	DUMPER SCREW E3520721000	HEAD 3 VACUUM ON CABLE E93207250A0
AC SERVO CONTROL PWB ASM E8602721AA0	CE OPERATION PWB ASM E8605721AA0	EJECTOR VBH 07 E3066700000	HEAD ENCODER RELAY CABLE ASM E93367250A0
AC SERVO DRIVER E9612721000	CHIP BOX ASM. E28017210A0	F EMERGENCY SW CABLE ASM. E94107250A0	HEAD MAIN PWB ASM E86077210A0
AC SERVO DRIVER 30W KM000000060	CIRCUIT PROTECTOR 10A HA00380000B	Feeder Bank Trunk Cable E93877210A0	HEAD MOTOR PWB ASM E86147210A0
AC SERVO MOTOR E9611721000	CONNECTOR FOR STICK FEEDER E95537160A0	FEEDER UNIT PWB ASM E86147150A0	HEAD PRESSURE SENSOR CABLE ASM E93157210A0
AIR COMBINATION PF0552120A0	CONVEYOR BELT E2056721000	FILTER (dia. 4.8mm id 2.9mm h 17.0mm) E3052729000	HEAD UP SP E3026725000
AIR CYLINDER PA0601011A0	CONVEYOR BELT E2216725000	FILTER (dia. 5.0mm id 2.0mm h 23.5mm) 40046646	HOD BOX CE VERSION E1700721A00
ARCNET PCB FOR ISA BUS E8651715AA0	CONVEYOR BELT E2217725000	FILTER ELEMENT VFL44	I/O CONTROL PWB ASM E86047210A0
ARCNET PWB ASM FOR ISA BUS E86117210A0	CONVEYOR BELT C (730/740 3 MOTOR) E2188721000	FILTER ELEMENT A PF901002000	Intelligent 12mm Tape Feeder RF-Type (for RS-1) RF12AS
ATC BASE E3453721000	CONVEYOR BELT S E2017725000	FILTER ELEMENT B PF901003000	Intelligent 16mm Tape Feeder RF-Type (for RS-1) RF16AS
ATC UNIT ASM (730) E34017210A0	CONVEYOR BELT S (730/740 3 MOTOR) E2189721000	FIXING PLATE B E2607721000	Intelligent 24mm Tape Feeder RF-Type (for RS-1) 40175380 RF24AS
ATC-ANGLE E3411715000	COUPLING FM740 E3023721000	Floating Joint E240676000	Intelligent 32mm Tape Feeder RF-Type (for RS-1) RF32AS
READER E32907210A0	COVER FUR (CE) E1130725000	FOCUS MODULAR LA UNIT E9635725000	
BALL SCREW E3024721000		Focused Modular E9635721000	
BASE UNIT PWB ASM E86167210A0	Cyberoptics Board PWA5120075		

Juki SMT Machine Spares

Intelligent 44mm Tape Feeder RF-Type (for RS-1) RF44AS	E365X729000 NOZZLE ASM 103 E35037210A0	RAIL SUPPORT SHEET E2164729C00B RAIL SUPPORT SHEET L 40008097	E3012721000 Tape feeder 12mm, Pitch adjustable (4/8/12) NF-12
Intelligent 56mm Tape Feeder RF-Type (for RS-1) RF56AS	Nozzle ASM for 0201 E35017250A0 NOZZLE ASSEMBLY 514 E36197290A0	RAIL SUPPORT U 40008095 REEL COLLAR 24mm PINK E6522705000	Tape feeder 12mm, Pitch adjustable (4/8/12) NF-12NS
Intelligent 8mm Tape Feeder RF-Type (for RS-1) RF08AS	Nozzle Assy, # 102-Melf E3502721MELF NOZZLE INNER 101 E3511721000	REEL COLLAR 8 NF08NS E6378705000 RELAY HB000630000	Tape feeder 16mm, Pitch adjustable (4/8/12) NF-16
Juki NOZZLE 201 dia. 3,5x1,5 E35517210A0	NOZZLE OUTER GUIDE E3030721000 NOZZLE PIN E3074700000	ROTARY BLOCK ASSEMBLY E30107210A0 SAFETY COVER STOPPER E1348700000	Tape feeder 16mm, Pitch adjustable (4/8/12) NF-16NS
Juki NOZZLE 202 dia. 5,5x3,2 E35527210A0	NOZZLE PIN E3074700000 NOZZLE PIN E3075700000	SCREW SUPPORT E3004721000 SENSOR MAGNET SWITCH E9607715B00	Tape feeder 24mm, Pitch adjustable (4/6/8/10) NF-24
Juki nozzle 500 Tip/Slider w/ rubber pad 400-11046-T	NOZZLE SLIDER 1 E3521721000 NOZZLE SLIDER 103 E3523721000	SERVO MOTOR 30W Z AXIS 40044534 SET COLLAR E3027721000	Tape feeder 24mm, Pitch adjustable (6/8/10/12) NF-24FS
JUKI NOZZLE 503 TIP/ SLIDER. \AA 1.0 / \AA 0.6 400-01341-T	NOZZLE SLIDER 104 E3524721000 NOZZLE SLIDER No 106 E3001705000	SIGNAL TOWER (LIGHT BULB) E9690715000 Stick feeder Lane No. 1-2, Comp.Types PLCC28/32, Lane Width .506"	Tape feeder 8mm Pitch (4), 7" reel NF-081E
JUKI NOZZLE 504 TIP/ SLIDER. \AA 1.6 / \AA 1.0 400-01342-T	NOZZLE SLIDER No 106 E3001705000 Nozzle Tip(Slider) Only (# 101 to # 106) E352X721000	Stick feeder Lane No. 1-2, Comp.Types PLCC28/32, Lane Width .506"	Tape feeder 8mm, Pitch (4), 15" reel NF-8L1E
JUKI NOZZLE 505 ASSY 40001343	OCC LIGHT PWB ASM E86127210A0 OCC RELAY CABLE ASM. E94527210A0	Stick feeder Lane No.1, Comp.Types PLCC68, Lane Width 1.006"	Tape feeder 8mm, Pitch adjustable (2/4), 15" reel NF-8LN
JUKI NOZZLE 505 TIP/ SLIDER. \AA 3.5 / \AA 1.7 400-01343-T	OPERATION PWB ASM E86057210A0 OUT SENSOR CABLE E94677250A0	Stick feeder Lane No.1, Comp.Types PLCC68, Lane Width 1.006"	Tape Feeder ATF 16mm Deep Pocket 18mm Pocket Depth AF16FS-DP
JUKI NOZZLE 506 TIP/ SLIDER. \AA 5.0 / \AA 3.2 400-01344-T	OUT SENSOR CABLE ASM E93617210A0 PHOTO INTERRUPTOR HD000670000	Stick feeder Lane No.1-2, Comp.Typ.SOIC8-16 u.PLCC52, Lane Width.251" - .806"	Tape Feeder ATF 24mm (Deep Pocket) AF24FS-OP
Keyboard Bracket E13097290A0	Power cable (6.2m) E94507000A0 POWER SUPPLY (12V/4.2A) HX004230000	Stick feeder Lane No.1-2, Comp.Typ.SOIC8-16 u.PLCC52, Lane Width.251" - .806"	Tape Feeder ATF 24mm, 15" reel holder AF24FS
LAHD CYBEROPTIC ASM. E9630721000	POWER SUPPLY (24V/10A) HX003240000 POWER SUPPLY (6V/4A) HX004220000	Stick feeder Lane No.1-2, Comp.Typ.SOIC8-16 u.PLCC52, Lane Width.251" - .806"	Tape Feeder ATF 8mm paper (splicing) 0402 (1005), Pitch 2mm, 7" reel AF05HP
LAHD Z1 MOTOR ASM E93077210A0	POWER SUPPLY 5V 30A (730/740) HX004420000 PROTECTOR 15A HA00380000C	Stick feeder Lane No.1-2, Comp.Typ.PLCC20, Lane Width .404"	Tape Feeder CTF 8mm embossed, Pitch 2mm, 7" reel CF08HE
LAIC HEAD Z AXIS MOTOR ASM E93037210A0	PULLEY XA 730/740 E2410721000 PWB INNER E2021721000	Stick feeder Lane No.1-2, Comp.Types PLCC20, Lane Width .404"	Tape Feeder CTF 8mm embossed, Pitch 4mm, 7" reel CF081E
LASER SENSOR FS730 6604054	R BANK UP DETECT CABLE ASM E95587210A0 RAIL SUPPORT E2129729000B	Stick feeder Lane No.1-2, Comp.Types SOL16-28, Lane Width .432" - .706"	Tape Feeder CTF 8mm embossed, Pitch 4mm, 7" reel CF081ER
LIMIT SENSOR HD000350000	RAIL SUPPORT C E2330729000A RAIL SUPPORT SHEET E2164729A00A	Stick feeder Lane No.1-4, Comp.Types SOIC 8-16, Lane Width .251"	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel CF08L1ER
LINEAR GUIDE E3022721000		Stick feeder Lane No.1-2, Comp.Types SOIC 8-16, Lane Width .251"	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel CF8L1E
MAGNET SCALE HEAD E9608721000		MBF44-SOIC SWING PLATE ASM E11067060A0A	Tape Feeder CTF 8mm for 0201 and 0402 for 7" Reel CF03HPR
MAGNETSCALE DETECTOR X-AXIS E9609725000		T BELT TENSIONER	Tape Feeder CTF 8mm paper 0402 (1005), Pitch 2mm, 7"
MC5M10HSV8S24B Ejector 70 ASM KE2070/2080 40050034			
MC5M10HSV8S24B Z1 Ejector ASM KE2070/2080 40045471			
MCMR, Four Channel, V 1.8 E9609729000A			
Mini Decompression Valve PC0205010A0 MNLA E9611729000			
MOTOR, THETA E93067210A0			
NOZZLE 500 TIP 1.0 X 0.5 (1005/1608)			

Juki SMT Machine Spares

reel	UNION FILTER	E1115706AB0	E1108706C00
CF05HP	PF010001000	KNOCK LEVER LINK ASM.	WHEEL COLLAR 03
Tape Feeder CTF 8mm paper,	UPPER COVER 1212 ASM	E1115706CB0	E1104706C00
Pitch 4mm, large reel	E32037060AC	LINK 12 ASM.	WHEEL PLATE 03
CF8L1P	UPPER COVER ASM for	E3115706AB0	E1130706C00
Tape Feeder CTFR 8mm Pitch	CF081E CF8L1E FF081E and	PRESSURE ROLLER (ATF)	WHEEL RING 03
4mm	FF8L1E	E1321706A00	E1109706C00
CF8L1ER	E2203706CA0	RATCHET HOOK STOPPER	X-Axis adjusting bracket asm.
Tape Feeder for 01005 1.115	Vacuum Filter RX-7	40081799	(CTF/ATF)
AQ02HP	40163249	REEL SUPPORT ARM ASM.	E1005-706-CA0
Tape Feeder FTF 12mm	VDS Display Monitor MIC-	E1610706AA0	X-AXIS POSITIONING PIN
standard, Pitch 4 - 12mm,	N952V-JK	SHAFT	E1002-706-000
15" reel	E94557150A0	E1314706A00	
FF12FS	VDS Display Monitor MJ-	SHAKE ARM (CTFR)	12/16/24MM FEEDER
Tape Feeder FTF 16mm	971Y7-JK 12V	40081807	E3292-760-000
standard, Pitch 4 - 12mm,	39.591.023	SHAKE ARM 4MM ASM	BEARING
15" reel	WAIT SENSOR CABLE A	40081827	SB304000100
FF16FS	E94647250A0	SHAKE ARM ASM	LINK 24ASM
Tape Feeder FTF 24mm	X AXIS CABLE BARE	E1303-706-0A0	E5115-706-0B0
standard, Pitch 8 - 24mm,	E2429715000	SHAKE ARM ASM)	LINK 24ASM (FF24mm)
15" reel	X AXIS PLASTIC RAIL ASM	E1303706AC0	E5115-706-0B0
FF24FS	20 with edge plates	SLIDE PLATE (ATF8mm)	LINK ASM
Tape Feeder FTF 32mm	40008068	E1115-706-A00	E3115-706-0B0
standard, Pitch 12 - 32mm,	X AXIS PLASTIC RAIL CHAIN	STOPPER CLICK	LINK ASM.
15" reel	40 (21 links)	40081800	E11157060B0
FF32FS	40008069	STOPPER HOOK	LOCK HOLDER SCREW
Tape Feeder FTF 44mm	X AXIS PLASTIC RAIL LINK	E1112-706-C0	E1523-706-C00
standard, Pitch 12 - 44mm,	40	STOPPER HOOK	OUT PUT GUIDE
15" reel	40008065	E1112-706-000-A	E7402706000
FF44FS	XY 4 SHAFT DRIVER(X	SWING PLATE 03 ASM.)	Pressure roller asm (ATF8mm)
Tape Feeder FTF 44mm, deep	SHAFT)	E1106706CB0	E1321-706-AA0
pocket, pocket depth 25mm	E9620729C00	SWING PLATE ASM	REEL HOUSING ASM
FF44DP	XY 4 SHAFT DRIVER(Y	E1106-706-0A0	E1304-706-0B0
Tape Feeder FTF 56mm	SHAFT)	TAPE HOLDER ASM.	REEL SHAFT
FF56FS	E9620729D00	E1310706CA0	E3306-706-000
Tape Feeder FTF 56mm	Y - AXIS CABLE BEARER	TAPE HOLDER PLATE	REEL SHAFT
standard, Pitch 12 - 16mm,	E2331715000	E1321706C00	E3306-706-000 JM
15" reel	Y AXIS PLASTIC RAIL (40)	TAPE HOLDER_ASM (CTFR)	REEL SHAFT (CTF)
FF564S	E2058729000	40081851	E1307-706-C00
Tape Feeder FTF 56mm	YA PULLEY BRACKET ASM	UP CV 08 ASM CTFR	REEL SHAFT 32R 1
standard, Pitch 12 - 32mm,	E23077210A0	40081845	E6666706R00
15" reel	Y-AXIS PLASTIC RAIL ASM	UP CV HOOK ASM	SHAKE ARM ASM
FF568S	(40) (only plastic rail)	40081910	E1303-706-0A0
Tape Feeder FTF 8mm paper	E2057729000	UPPER COVER 05 ASM (ATF)	SHUTTER PLATE 32 ASM.
(0402)	Y-AXIS PLASTIC RAIL ASM	E1201-706-AA0	E6220706A00
FF08HE	20 (2010/2020 L)	UPPER COVER 08ASM	ST PL BK 1
Tape Feeder FTF 8mm, Pitch	40017719	E1202-706-AA0	E6125706R00
4mm, 15" reel	Z SLIDE BRACKET	UPPER COVER 1212 ASM.	STOPPER 12/16/24-NS
FF8L1E	E3007721000	E3203706AACA	E313070600E
Tape Feeder FTF 8mm, Pitch	Z SLIDER SHAFT	UPPER COVER 1612 ASM.	STOPPER 8x2)
4mm, 7" reel	E3008721000	E4203706AACA	E6822-705-000
FF081E	Z-SLIDE SHAFT A	UPPER COVER 2424 ASM.	STOPPER HOOK
Tape Feeder FTFR 32mm	E30067250A0	E5203706AAE	E1112-706-000-A
(Deep Pocket)	Z-SLIDE SHAFT IC ASM	UPPER COVER ASM(3).	SUTTER PLATE 32 ASM. 1
FF32FR-OP	E32067250A0	E1202-706-CA0	E6220706AA0
Tape Feeder FTFR 44mm	BEARING	UPPER COVER ASM(5).	SWING PLATE ASM
(Deep Pocket)	SB304000100	E1203-706-CA0	E3106-706-0A0
FF44FR-OP	CLUTCH HOLDER ASM.	UPPER COVER HOOK	SWING PLATE ASM.
Tape Feeder FTFR 56mm	E1301706AA0	E1211-706-C00-A	E61067060A0
FF56FR-OP	HOLDER_PLATE_ASM CTFR	UPPER COVER SHAFT	TAPE HOLDER ASM (CTF)
TAPE HOLDER 12 ASM	40081848	E1209-706-000	E1310-706-CA0
E33107060A0A	HOLDER_SH CTFR	UPPER COVER SHAFT (CTF)	TAPE HOLDER ASM.
THETA COUPLING	40081849	E1209-706-C00	E1310-706-0A0
E3025725000	HOUSING ASM	WHEEL ASM (Sprocket)	TAPE HOLDER ASM.
THETA PULLEY	E1304-706-CA0	E1102-706-0A0	E6310-706-0A0-A
E3011721000	KNOCK LEVER LINK ASM.	WHEEL BUSH SPACER 03	

Juki SMT Machine Spares

TAPE HOLDER ASM. E3310-706-0A0	E86087290B0	Nozzle HOLDER E3051729000	FILTER 4000200
TAPE HOLDER ASM. (FTF44mmmm)	Valve E93188020A0	Filter E3052729000	FILTER 4000300
E7310-706-0A0-A	Sensor ASM E93208550A0	Valve E3066700000	0.4 VCS LIGHT PWB ASM E86157210A0
UPPER COVER 08 ASM. E2203-706-CA0	Parallel CABLE E93237290A0	Shaft IC E3141729000	2-Lane Belt Feeder, SOW (2 SOWIC) MBF44-SOW
UPPER COVER 1204 ASM E3203-706-0AA	Trunk CABLE E93287210A0	Filter element E3273729000	2-Lane Belt Feeder, SOY (2 SOYIC) MBF44-SOY
UPPER COVER 1208 ASM E3203-706-0AB	Cable ASM E93367210A0	E NOZZLE E3571721000	3-Lane Belt Feeder, 2 .300", 1 .400", SOJ (2x.3" SOJ + 1 .4" SOJ) MBF44-SOJ
UPPER COVER 1212 ASM . E3203-706-0AC	Cable E93367250A0	Calibration jigs E3622721000	AC SERVO CONTROL PWB ASM E86027210A0
UPPER COVER 1604 ASM E4203-706-0AA	Cable E93407250A0	Linear WAY E4211717000	AC SERVO CONTROL PWB ASM E8602721AA0
UPPER COVER 1608 ASM (2) E4203-706-0AB	Sensor E93587150A0	Conveyor BELT E4256729000	AC SERVO DRIVER E9612721000
UPPER COVER 1612 ASM . E4203-706-0AC	Sensor E94647250A0	Conveyor BELT E4257729000	AC SERVO DRIVER 30W KM000000060
UPPER COVER 2408 ASM E5203-706-00A	Board E96567290A0	Chain CABLE E8736725000	AC SERVO MOTOR E9611721000
UPPER COVER 2412 ASM (3). E5203-706-0AB	Tang CHAIN E205572900	Detector X E9609725000	AIR COMBINATION PF0552120A0
UPPER COVER 2416 ASM E5203-706-0AC	Timing BELT E323725000	Msm CARD E9609729000	AIR CYLINDER PA0601011A0
UPPER COVER 2424 ASM E5203-706-0AD	Chain TABLE E873572000	Laser BOARD E9610729000	ARCNET PCB FOR ISA BUS E8651715AA0
UPPER COVER 3212ST E6203706RB0	Ball SLIDE 1045 E1107717000	Laser E9611729000	ARCNET PWB ASM FOR ISA BUS E86117210A0
UPPER COVER 3232ASM E6203-706-0AC	Spring A E1480729000	Driver E9612721000	ATC BASE E3453721000
UPPER COVER 4444ASM E7203-706-0AC	Belt E2004729000	Photo INTERRUPTER E9613717000	ATC UNIT ASM (730) E34017210A0
UPPER COVER SHAFT E1209-706-000	Belt YBE E2009729000	Motor E9624729000	ATC-ANGLE E3411715000
WHEEL ASM (Sprocket) E1102-706-0A0	Belt C E2016725000	Board E9626729000	READER E32907210A0
X-AXIS POSITIONING PIN ASM (FTF)	Belt S E2017725000	Motor E9629729000	BALL SCREW E3024721000
E1001-706-0A0-AXMP(MAIN)	Rail ASM E2055729000	Land ASM E9630721000	BASE UNIT PWB ASM E86167210A0
E9606729000	Rail ASM E2058729000	Motor E9630729000	BEARING FOR YA PULLEY BRACKET B3406180000
XMP(4SE/4ST) E9607729000	Timing BELT E2107729000	Laser E9631721000	BEARING NO. 41 SB112000600
MCM(4 SHAFT) E9609729000	Rubber RING E2151723000	Servo MOTOR E9631729000	BOC CAMERA CABLE ASM E94587150A0
UPS E9659729000	Air CYLINDER E2254802000	Driver E9635721000	BU DOWN SENSOR E94697250A0
XY 4 SHAFT DRIVER E9620729000	Belt E2306725000	Laser E9635725000	BU UP SENSOR E94687250A0
YC 1 SHAFT DRIVER E9621729000	Timing BELT E2308725000	Hod ASM E9649729000	C OUT SENSOR CABLE ASM E93637210A0
DRIVER E9626729000	Bearer ASM E2330725000	Driver EE085U001	CAM FOLLOWER RETURN SPRING E1327706000
STEP DRIVER HX004200000	Rail ASSY E2331715000	Ejector valve 40010678	CARRY PWB A
MAGNESCALE DETECTOR E9641729000	Timing BELT E2432725000		
SENSOR HEAD (X8M) E9641729B00	Belt E3014729000		
SENSOR HEAD (Y8M) E9641729C00	Belt Z E3021729000		
CPU BOARD ASM E96567290A0	Timing BELT E3023725000		
MOTOR DRIVER HX005450000			
CPU Board			

Juki SMT Machine Spares

E86177210A0	FILTER ELEMENT	RF56AS	NOZZLE ASSEMBLY 514
CARRY PWB ASM	VFL44	Intelligent 8mm Tape Feeder	E36197290A0
E86067210A0	FILTER ELEMENT A	RF-Type (for RS-1)	Nozzle Assy, # 102-Melf
CE OPERATION PWB ASM	PF901002000	RF08AS	E3502721MELF
E8605721AA0	FILTER ELEMENT B	Juki NOZZLE 201 dia. 3,5x1,5	NOZZLE INNER 101
CHIP BOX ASM.	PF901003000	E35517210A0	E3511721000
E28017210A0	FIXING PLATE B	Juki NOZZLE 202 dia. 5,5x3,2	NOZZLE OUTER GUIDE
CIRCUIT PROTECTOR 10A	E2607721000	E35527210A0	E3030721000
HA00380000B	Floating Joint	Juki nozzle 500 Tip/Slider w/	NOZZLE PIN
CONNECTOR FOR STICK	E240676000	rubber pad	E3074700000
FEEDER	FOCUS MODULAR LA UNIT	400-11046-T	NOZZLE PIN
E95537160A0	E9635725000	JUKI NOZZLE 503 TIP/	E3075700000
CONVEYOR BELT	Focused Modular	SLIDER. \pm 1.0 / \pm 0.6	NOZZLE SLIDER 1
E2056721000	E9635721000	400-01341-T	E3521721000
CONVEYOR BELT	FX-1/R ZT SERVO AMP	JUKI NOZZLE 504 TIP/	NOZZLE SLIDER 103
E2216725000	L901E521000	SLIDER. \pm 1.6 / \pm 1.0	E3523721000
CONVEYOR BELT	Gantry drive motor Juki	400-01342-T	NOZZLE SLIDER 104
E2217725000	KE2050-L, x-axis (Tamagawa	JUKI NOZZLE 505 ASSY	E3524721000
CONVEYOR BELT C (730/740	Seiki TS)	40001343	NOZZLE SLIDER No 106
3 MOTOR)	4613N1020E200	JUKI NOZZLE 505 TIP/	E3001705000
E2188721000	GAS SPRING 730-760 CE	SLIDER. \pm 3.5 / \pm 1.7	Nozzle Tip(Slider) Only (# 101
CONVEYOR BELT S	E5154715000	400-01343-T	to # 106)
E2017725000	GREASE	JUKI NOZZLE 506 TIP/	E352X721000
CONVEYOR BELT S (730/740	MGREAS400G0	SLIDER. \pm 5.0 / \pm 3.2	OCC LIGHT PWB ASM
3 MOTOR)	HAND VALVE	400-01344-T	E86127210A0
E2189721000	PV010006000	Keyboard Bracket	OCC RELAY CABLE ASM.
COUPLING FM740	HARD DISC ASM JE	E13097290A0	E94527210A0
E3023721000	40002937	LAHD CYBEROPTIC ASM.	OPERATION PWB ASM
COVER FUR (CE)	HEAD 1 VACUUM ON CABLE	E9630721000	E86057210A0
E1130725000	ASM	LAHD Z1 MOTOR ASM	OUT SENSOR CABLE
Cyberoptics Board	E93147210A0	E93077210A0	E94677250A0
PWA5120075	HEAD 3 VACUUM ON CABLE	LAIC HEAD Z AXIS MOTOR	OUT SENSOR CABLE ASM
Cyberoptics Board	E93207250A0	ASM	E93617210A0
PWA8002763	HEAD ENCODER RELAY	E93037210A0	PHOTO INTERRUPTOR
DC SERVO CONTROL PWB	CABLE ASM	LASER SENSOR FS730	HD000670000
ASM	E93367250A0	6604054	Power cable (6.2m)
E86037210A0	HEAD MAIN PWB ASM	LIMIT SENSOR	E94507000A0
DEFRIX OIL No1	E86077210A0	HD000350000	POWER SUPPLY (12V/4.2A)
MDFRX1001LO	HEAD MOTOR PWB ASM	LINEAR GUIDE	HX004230000
DEFRIX OIL No2	E86147210A0	E3022721000	POWER SUPPLY (24V/10A)
MDFRX2001LO	HEAD PRESSURE SENSOR	MAGNET SCALE HEAD	HX003240000
DOOR PIVOT BLOCK	CABLE ASM	E9608721000	POWER SUPPLY (6V/4A)
E4504717000	E93157210A0	MAGNETSCALE DETECTOR	HX004220000
DOS FORMAT HDD ASM	HEAD UP SP	X-AXIS	POWER SUPPLY 5V 30A
40010251	E3026725000	E9609725000	(730/740)
DOS FORMAT SDD 128MB	HOD BOX CE VERSION	MC5M10HSV8S24B Ejector	HX004420000
40031401	E1700721A00	70 ASM KE2070/2080	PROTECTOR 15A
DRIVE BELT	I/O CONTROL PWB ASM	40050034	HA00380000C
E2051721000	E86047210A0	MC5M10HSV8S24B Z1	PULLEY XA 730/740
DUMPER SCREW	Intelligent 12mm Tape Feeder	Ejector ASM KE2070/2080	E2410721000
E3520721000	RF-Type (for RS-1)	40045471	PWB INNER
EJECTOR VBH 07	RF12AS	MCMR, Four Channel, V 1.8	E2021721000
E3066700000	Intelligent 16mm Tape Feeder	E9609729000A	R BANK UP DETECT CABLE
F EMERGENCY SW CABLE	RF-Type (for RS-1)	Mini Decompression Valve	ASM
ASM.	RF16AS	PC0205010A0	E95587210A0
E94107250A0	Intelligent 24mm Tape Feeder	MNLA	RAIL SUPPORT
Feeder Bank Trunk Cable	RF-Type (for RS-1) 40175380	E9611729000	E2129729000B
E93877210A0	RF24AS	MOTOR, THETA	RAIL SUPPORT C
FEEDER UNIT PWB ASM	Intelligent 32mm Tape Feeder	E93067210A0	E2330729000A
E86147150A0	RF-Type (for RS-1)	NOZZLE 500 TIP 1.0 X 0.5	RAIL SUPPORT SHEET
FILTER (dia. 4.8mm id 2.9mm	RF32AS	(1005/1608)	E2164729A00A
h 17.0mm)	Intelligent 44mm Tape Feeder	E365X729000	RAIL SUPPORT SHEET
E3052729000	RF-Type (for RS-1)	NOZZLE ASM 103	E2164729C00B
FILTER (dia. 5.0mm id 2.0mm	RF44AS	E35037210A0	RAIL SUPPORT SHEET L
h 23.5mm)	Intelligent 56mm Tape Feeder	Nozzle ASM for 0201	40008097
40046646	RF-Type (for RS-1)	E35017250A0	RAIL SUPPORT U

Juki SMT Machine Spares

40008095	NF-12NS	CF8L1ER	Vacuum Filter RX-7
REEL COLLAR 24mm PINK	Tape feeder 16mm, Pitch adjustable (4/8/12)	Tape Feeder for 01005 1.115	40163249
E6522705000	NF-16	AQ02HP	VDS Display Monitor MIC-N952V-JK
REEL COLLAR 8 NF08NS	Tape feeder 16mm, Pitch adjustable (4/8/12)	Tape Feeder FTF 12mm standard, Pitch 4 - 12mm, 15" reel	E94557150A0
E6378705000	NF-16NS	FF12FS	VDS Display Monitor MJ-971Y7-JK 12V
RELAY	Tape feeder 24mm, Pitch adjustable (4/6/8/10)	Tape Feeder FTF 16mm standard, Pitch 4 - 12mm, 15" reel	39.591.023
HB000630000	NF-24	FF16FS	WAIT SENSOR CABLE A
ROTARY BLOCK ASSEMBLY	Tape feeder 24mm, Pitch adjustable (6/8/10/12)	Tape Feeder FTF 24mm standard, Pitch 8 - 24mm, 15" reel	E94647250A0
E30107210A0	NF-24FS	FF24FS	X AXIS CABLE BARE
SAFETY COVER STOPPER	Tape feeder 8mm Pitch (4), 7" reel	Tape Feeder FTF 32mm standard, Pitch 12 - 32mm, 15" reel	E2429715000
E1348700000	NF-081E	FF32FS	X AXIS PLASTIC RAIL ASM
Screw	Tape feeder 8mm, Pitch adjustable (2/4), 15" reel	FF44FS	X axis with edge plates
SM8060502TP	NF-8L1E	Tape Feeder FTF 44mm standard, Pitch 12 - 44mm, 15" reel	40008068
SCREW SUPPORT	Tape feeder 8mm, Pitch adjustable (2/4), 7" reel	FF44FS	X AXIS PLASTIC RAIL CHAIN
E3004721000	NF-08N	Tape Feeder FTF 44mm, deep pocket, pocket depth 25mm	40 (21 links)
SENSOR MAGNET SWITCH	Tape Feeder ATF 16mm Deep Pocket 18mm Pocket Depth	FF44DP	40008069
E9607715B00	AF16FS-DP	Tape Feeder FTF 56mm	X AXIS PLASTIC RAIL LINK
SERVO MOTOR 30W Z AXIS	Tape Feeder ATF 24mm (Deep Pocket)	FF56FS	40
40044534	AF24FS-OP	Tape Feeder FTF 56mm standard, Pitch 12 - 16mm, 15" reel	40008065
SET COLLAR	Tape Feeder ATF 24mm, 15" reel holder	FF564S	XY 4 SHAFT DRIVER(X SHAFT)
E3027721000	AF24FS	Tape Feeder FTF 56mm standard, Pitch 12 - 32mm, 15" reel	E9620729C00
SIGNAL TOWER (LIGHT BULB)	Tape Feeder ATF 8mm paper (splicing) 0402 (1005), Pitch 2mm, 7" reel	FF568S	XY 4 SHAFT DRIVER(Y SHAFT)
E9690715000	AF05HP	Tape Feeder FTF 8mm paper (0402)	E9620729D00
Stick feeder Lane No. 1-2, Comp.Types PLCC28/32, Lane Width .506"	Tape Feeder CTF 8mm embossed, Pitch 2mm, 7" reel	FF08HE	E9620729D00
MBF44-PLCC28/32	CF08HE	Tape Feeder FTF 8mm, Pitch 4mm, 15" reel	Y - AXIS CABLE BEARER
Stick feeder Lane No.1, Comp.Types PLCC68, Lane Width 1.006"	Tape Feeder CTF 8mm embossed, Pitch 4mm, 7" reel	FF8L1E	E2331715000
MBF44-PLCC68	CF081E	Tape Feeder FTF 8mm, Pitch 4mm, 7" reel	Y AXIS PLASTIC RAIL (40)
Stick feeder Lane No.1, Comp.Types PLCC84, Lane Width 1.206"	Tape Feeder CTF 8mm embossed, Pitch 4mm, 7" reel	FF081E	E2058729000
MBF44-PLCC84	CF081ER	Tape Feeder FTFR 32mm (Deep Pocket)	YA PULLEY BRACKET ASM
Stick feeder Lane No.1-2, Comp.Typ.SOIC8-16 u.PLCC52, Lane Width.251" - .806"	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel	FF32FR-OP	E23077210A0
MBF44-PLCC52/SOIC	CF08L1ER	Tape Feeder FTFR 44mm (Deep Pocket)	Y-AXIS PLASTIC RAIL ASM (40) (only plastic rail)
Stick feeder Lane No.1-2,Comp.Typ.SOL16-28 u.PLCC44, Lane Width.432" - .706"	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel	FF44FR-OP	E2057729000
MBF44-PLCC44/SOL	CF8L1E	Tape Feeder FTFR 56mm	Y-AXIS PLASTIC RAIL ASM 20 (2010/2020 L)
Stick feeder Lane No.1-2,Comp.Types PLCC20, Lane Width .404"	Tape Feeder CTF 8mm for 0201 and 0402 for 7" Reel	FF56FR-OP	40017719
MBF44-PLCC20	CF03HPR	TAPE HOLDER 12 ASM	Z SLIDE BRACKET
Stick feeder Lane No.1-2,Comp.Types SOIC 8-16, Lane Width .251"	Tape Feeder CTF 8mm paper 0402 (1005), Pitch 2mm, 7" reel	E33107060A0A	E3007721000
MBF44-SOIC	CF05HP	THETA COUPLING	Z SLIDER SHAFT
SWING PLATE ASM	Tape Feeder CTF 8mm paper, Pitch 4mm, large reel	E3025725000	E3008721000
E11067060A0A	CF8L1P	THETA PULLEY	Z-SLIDE SHAFT A
T BELT TENSIONER	Tape Feeder CTFR 8mm Pitch 4mm	E3011721000	E30067250A0
E3012721000		UNION FILTER	Z-SLIDE SHAFT IC ASM
Tape feeder 12mm, Pitch adjustable (4/8/12)		PF010001000	E32067250A0
NF-12		UPPER COVER 1212 ASM	BEARING
Tape feeder 12mm, Pitch adjustable (4/8/12)		E32037060AC	SB304000100
		UPPER COVER ASM for CF081E CF8L1E FF081E and FF8L1E	CLUTCH HOLDER ASM.
		E2203706CA0	E1301706AA0
			HOLDER_PLATE_ASM CTFR
			40081848
			HOLDER_SH CTFR
			40081849
			HOUSING ASM
			E1304-706-CA0
			KNOCK LEVER LINK ASM.
			E1115706AB0
			KNOCK LEVER LINK ASM.
			E1115706CB0
			LINK 12 ASM.
			E3115706AB0
			PRESSURE ROLLER (ATF)
			E1321706A00
			RATCHET HOOK STOPPER
			40081799

Juki SMT Machine Spares

REEL SUPPORT ARM ASM. E1610706AA0 SHAFT E1314706A00 SHAKE ARM (CTFR) 40081807 SHAKE ARM 4MM ASM 40081827 SHAKE ARM ASM E1303-706-0A0 SHAKE ARM ASM) E1303706AC0 SLIDE PLATE (ATF8mm) E1115-706-A00 STOPPER CLICK 40081800 STOPPER HOOK E1112-706-C0 STOPPER HOOK E1112-706-000-A SWING PLATE 03 ASM.) E1106706CB0 SWING PLATE ASM E1106-706-0A0 TAPE HOLDER ASM. E1310706CA0 TAPE HOLDER PLATE E1321706C00 TAPE HOLDER_ASM (CTFR) 40081851 UP CV 08 ASM □ CTFR □ 40081845 UP CV HOOK ASM 40081910 UPPER COVER 05 ASM (ATF) E1201-706-AA0 UPPER COVER 08ASM E1202-706-AA0 UPPER COVER 1212 ASM. E3203706AACA UPPER COVER 1612 ASM. E4203706AACA UPPER COVER 2424 ASM. E5203706AAE UPPER COVER ASM(3). E1202-706-CA0 UPPER COVER ASM(5). E1203-706-CA0 UPPER COVER HOOK E1211-706-C00-A UPPER COVER SHAFT E1209-706-000 UPPER COVER SHAFT (CTF) E1209-706-C00 WHEEL ASM (Sprocket) E1102-706-0A0 WHEEL BUSH SPACER 03 E1108706C00 WHEEL COLLAR 03 E1104706C00 WHEEL PLATE 03 E1130706C00 WHEEL RING 03 E1109706C00 X-Axis adjusting bracket asm. (CTF/ATF) E1005-706-CA0	X-AXIS POSITIONING PIN E1002-706-000 12/16/24MM FEEDER E3292-760-000 BEARING SB304000100 LINK 24ASM E5115-706-0B0 LINK 24ASM (FF24mm) E5115-706-0B0 LINK ASM E3115-706-0B0 LINK ASM. E11157060B0 LOCK HOLDER SCREW E1523-706-C00 OUT PUT GUIDE E7402706000 Pressure roller asm (ATF8mm) E1321-706-AA0 REEL HOUSING ASM E1304-706-0B0 REEL SHAFT E3306-706-000 REEL SHAFT E3306-706-000 JM REEL SHAFT (CTF) E1307-706-C00 REEL SHAFT 32R 1 E6666706R00 SHAKE ARM ASM E1303-706-0A0 SHUTTER PLATE 32 ASM. E62207060A0 ST PL BK 1 E6125706R00 STOPPER 12/16/24-NS E313070600E STOPPER 8×2) E6822-705-000 STOPPER HOOK E1112-706-000-A SUTTER PLATE 32 ASM. 1 E6220706AA0 SWING PLATE ASM E3106-706-0A0 SWING PLATE ASM. E61067060A0 TAPE HOLDER ASM (CTF) E1310-706-CA0 TAPE HOLDER ASM. E1310-706-0A0 TAPE HOLDER ASM. E6310-706-0A0-A TAPE HOLDER ASM. E3310-706-0A0 TAPE HOLDER ASM. (FTF44mmmm) E7310-706-0A0-A UPPER COVER 08 ASM. E2203-706-CA0 UPPER COVER 1204 ASM E3203-706-OAA UPPER COVER 1208 ASM E3203-706-OAB	UPPER COVER 1212 ASM . E3203-706-0AC UPPER COVER 1604 ASM E4203-706-OAA UPPER COVER 1608 ASM (2) E4203-706-0AB UPPER COVER 1612 ASM . E4203-706-0AC UPPER COVER 2408 ASM E5203-706-00A UPPER COVER 2412 ASM (3). E5203-706-0AB UPPER COVER 2416 ASM E5203-706-0AC UPPER COVER 2424 ASM E5203-706-0AD UPPER COVER 3212ST E6203706RB0 UPPER COVER 3232ASM E6203-706-0AC UPPER COVER 4444ASM E7203-706-0AC UPPER COVER SHAFT E1209-706-000 WHEEL ASM (Sprocket) E1102-706-0A0 X-AXIS POSITIONING PIN ASM (FTF) E1001-706-0A0-A XMP(MAIN) E9606729000 XMP(4SE/4ST) E9607729000 MCM(4 SHAFT) E9609729000 UPS E9659729000 XY 4 SHAFT DRIVER E9620729000 YC 1 SHAFT DRIVER E9621729000 DRIVER E9626729000 STEP DRIVER HX004200000 MAGNESCALE DETECTOR E9641729000 SENSOR HEAD (X8M) E9641729B00 SENSOR HEAD (Y8M) E9641729C00 CPU BOARD ASM E96567290A0 MOTOR DRIVER HX005450000 CPU Board E86087290B0 Valve E93188020A0 Sensor ASM E93208550A0 Parallel CABLE E93237290A0 Trunk CABLE E93287210A0 Cable ASM	E93367210A0 Cable E93367250A0 Cable E93407250A0 Sensor E93587150A0 Sensor E94647250A0 Board E96567290A0 Tang CHAIN E205572900 Timing BELT E323725000 Chain TABLE E873572000 Ball SLIDE 1045 E1107717000 Spring A E1480729000 Belt E2004729000 Belt YBE E2009729000 Belt C E2016725000 Belt S E2017725000 Rail ASM E2055729000 Rail ASM E2058729000 Timing BELT E2107729000 Rubber RING E2151723000 Air CYLINDER E2254802000 Belt E2306725000 Timing BELT E2308725000 Bearer ASM E2330725000 Rail ASSY E2331715000 Timing BELT E2432725000 Belt E3014729000 Belt Z E3021729000 Timing BELT E3023725000 Nozzle HOLDER E3051729000 Filter E3052729000 Valve E3066700000 Shaft IC E3141729000 Filter element E3273729000 E NOZZLE E3571721000
---	---	--	---

Juki SMT Machine Spares

Calibration jigs E3622721000	SENSOR HEAD (X8M) E9641729B00	Timing BELT E2432725000	FILTER 4000200
Linear WAY E4211717000	SENSOR HEAD (Y8M) E9641729C00	Belt E3014729000	FILTER 4000300
Conveyor BELT E4256729000	CPU BOARD ASM E96567290A0	Belt Z E3021729000	0.4 VCS LIGHT PWB ASM E86157210A0
Conveyor BELT E4257729000	MOTOR DRIVER HX005450000	Timing BELT E3023725000	2-Lane Belt Feeder, SOW (2 SOWIC)
Chain CABLE E8736725000	CPU Board E86087290B0	Nozzle HOLDER E3051729000	MBF44-SOW 2-Lane Belt Feeder, SOY (2 SOYIC)
Detector X E9609725000	Valve E93188020A0	Filter E3052729000	MBF44-SOY 3-Lane Belt Feeder, 2 .300", 1 .400", SOJ (2x.3" SOJ + 1 .4" SOJ)
Msm CARD E9609729000	Sensor ASM E93208550A0	Valve E3066700000	MBF44-SOJ AC SERVO CONTROL PWB ASM
Laser BOARD E9610729000	Parallel CABLE E93237290A0	Shaft IC E3141729000	E86027210A0 AC SERVO CONTROL PWB ASM
Laser E9611729000	Trunk CABLE E93287210A0	Filter element E3273729000	E8602721AA0 AC SERVO DRIVER
Driver E9612721000	Cable ASM E93367210A0	E NOZZLE E3571721000	E9612721000 AC SERVO DRIVER 30W KM000000060
Photo INTERRUPTER E9613717000	Cable E93367250A0	Calibration jigs E3622721000	AC SERVO MOTOR E9611721000
Motor E9624729000	Cable E93407250A0	Linear WAY E4211717000	AIR COMBINATION PF0552120A0
Board E9626729000	Sensor E93587150A0	Conveyor BELT E4256729000	AIR CYLINDER PA0601011A0
Motor E9629729000	Sensor E94647250A0	Conveyor BELT E4257729000	ARCNET PCB FOR ISA BUS E8651715AA0
Land ASM E9630721000	Board E96567290A0	Chain CABLE E8736725000	ARCNET PWB ASM FOR ISA BUS
Motor E9630729000	Tang CHAIN E205572900	Detector X E9609725000	E86117210A0 ATC BASE
Laser E9631721000	Timing BELT E323725000	Msm CARD E9609729000	E3453721000 ATC UNIT ASM (730)
Servo MOTOR E9631729000	Chain TABLE E873572000	Laser BOARD E9610729000	E34017210A0 ATC-ANGLE
Driver E9635721000	Ball SLIDE 1045 E1107717000	Laser E9611729000	E3411715000 READER
Laser E9635725000	Spring A E1480729000	Driver E9612721000	E32907210A0 BALL SCREW
Hod ASM E9649729000	Belt E2004729000	Photo INTERRUPTER E9613717000	E3024721000 BASE UNIT PWB ASM
Driver EE085U001	Belt YBE E2009729000	Motor E9624729000	E86167210A0 BEARING FOR YA PULLEY
	Belt C E2016725000	Board E9626729000	BRACKET B3406180000
	Belt S E2017725000	Motor E9629729000	BEARING NO. 41 SB112000600
Ejector valve 40010678	Rail ASM E2055729000	Land ASM E9630721000	BOC CAMERA CABLE ASM E94587150A0
XMP(MAIN) E9606729000	Rail ASM E2058729000	Motor E9630729000	BU DOWN SENSOR E94697250A0
XMP(4SE/4ST) E9607729000	Timing BELT E2107729000	Laser E9631721000	BU UP SENSOR E94687250A0
MCM(4 SHAFT) E9609729000	Rubber RING E2151723000	Servo MOTOR E9631729000	C OUT SENSOR CABLE ASM E93637210A0
UPS E9659729000	Air CYLINDER E2254802000	Driver E9635721000	CAM FOLLOWER RETURN SPRING
XY 4 SHAFT DRIVER E9620729000	Belt E2306725000	Laser E9635725000	E1327706000 CARRY PWB A
YC 1 SHAFT DRIVER E9621729000	Timing BELT E2308725000	Hod ASM E9649729000	
DRIVER E9626729000	Bearer ASM E2330725000	Driver EE085U001	
STEP DRIVER HX004200000	Rail ASSY E2331715000	Ejector valve 40010678	
MAGNESCALE DETECTOR E9641729000			

Juki SMT Machine Spares

E86177210A0	VFL44	RF-Type (for RS-1)	E3502721MELF
CARRY PWB ASM	FILTER ELEMENT A	RF08AS	NOZZLE INNER 101
E86067210A0	PF901002000	Juki NOZZLE 201 dia. 3,5x1,5	E3511721000
CE OPERATION PWB ASM	FILTER ELEMENT B	E35517210A0	NOZZLE OUTER GUIDE
E8605721AA0	PF901003000	Juki NOZZLE 202 dia. 5,5x3,2	E3030721000
CHIP BOX ASM.	FIXING PLATE B	E35527210A0	NOZZLE PIN
E28017210A0	E2607721000	Juki nozzle 500 Tip/Slider w/	E3074700000
CIRCUIT PROTECTOR 10A	Floating Joint	rubber pad	NOZZLE PIN
HA00380000B	E240676000	400-11046-T	E3075700000
CONNECTOR FOR STICK	FOCUS MODULAR LA UNIT	JUKI NOZZLE 503 TIP/	NOZZLE SLIDER 1
FEEDER	E9635725000	SLIDER. \pm 1.0 / \pm 0.6	E3521721000
E95537160A0	Focused Modular	400-01341-T	NOZZLE SLIDER 103
CONVEYOR BELT	E9635721000	JUKI NOZZLE 504 TIP/	E3523721000
E2056721000	FX-1/R ZT SERVO AMP	SLIDER. \pm 1.6 / \pm 1.0	NOZZLE SLIDER 104
CONVEYOR BELT	L901E521000	400-01342-T	E3524721000
E2216725000	Gantry drive motor Juki	JUKI NOZZLE 505 ASSY	NOZZLE SLIDER No 106
CONVEYOR BELT	KE2050-L, x-axis (Tamagawa	40001343	E3001705000
E2217725000	Seiki TS)	JUKI NOZZLE 505 TIP/	Nozzle Tip(Slider) Only (# 101
CONVEYOR BELT C (730/740	4613N1020E200	SLIDER. \pm 3.5 / \pm 1.7	to # 106)
3 MOTOR)	GAS SPRING 730-760 CE	400-01343-T	E352X721000
E2188721000	E5154715000	JUKI NOZZLE 506 TIP/	OCC LIGHT PWB ASM
CONVEYOR BELT S	GREASE	SLIDER. \pm 5.0 / \pm 3.2	E86127210A0
E2017725000	MGREAS400G0	400-01344-T	OCC RELAY CABLE ASM.
CONVEYOR BELT S (730/740	HAND VALVE	Keyboard Bracket	E94527210A0
3 MOTOR)	PV010006000	E13097290A0	OPERATION PWB ASM
E2189721000	HARD DISC ASM JE	LAHD CYBEROPTIC ASM.	E86057210A0
COUPLING FM740	40002937	E9630721000	OUT SENSOR CABLE
E3023721000	HEAD 1 VACUUM ON CABLE	LAHD Z1 MOTOR ASM	E94677250A0
COVER FUR (CE)	ASM	E93077210A0	OUT SENSOR CABLE ASM
E1130725000	E93147210A0	LAIC HEAD Z AXIS MOTOR	E93617210A0
Cyberoptics Board	HEAD 3 VACUUM ON CABLE	ASM	PHOTO INTERRUPTOR
PWA5120075	E93207250A0	E93037210A0	HD000670000
Cyberoptics Board	HEAD ENCODER RELAY	LASER SENSOR FS730	Power cable (6.2m)
PWA8002763	CABLE ASM	6604054	E94507000A0
DC SERVO CONTROL PWB	E93367250A0	LIMIT SENSOR	POWER SUPPLY (12V/4.2A)
ASM	HEAD MAIN PWB ASM	HD000350000	HX004230000
E86037210A0	E86077210A0	LINEAR GUIDE	POWER SUPPLY (24V/10A)
DEFRIX OIL No1	HEAD MOTOR PWB ASM	E3022721000	HX003240000
MDFRX1001LO	E86147210A0	MAGNET SCALE HEAD	POWER SUPPLY (6V/4A)
DEFRIX OIL No2	HEAD PRESSURE SENSOR	E9608721000	HX004220000
MDFRX2001LO	CABLE ASM	MAGNETSCALE DETECTOR	POWER SUPPLY 5V 30A
DOOR PIVOT BLOCK	E93157210A0	X-AXIS	(730/740)
E4504717000	HEAD UP SP	E9609725000	HX004420000
DOS FORMAT HDD ASM	E3026725000	MC5M10HSV8S24B Ejector	PROTECTOR 15A
40010251	HOD BOX CE VERSION	70 ASM KE2070/2080	HA00380000C
DOS FORMAT SDD 128MB	E1700721A00	40050034	PULLEY XA 730/740
40031401	I/O CONTROL PWB ASM	MC5M10HSV8S24B Z1	E2410721000
DRIVE BELT	E86047210A0	Ejector ASM KE2070/2080	PWB INNER
E2051721000	Intelligent 12mm Tape Feeder	40045471	E2021721000
DUMPER SCREW	RF-Type (for RS-1)	MCMR, Four Channel, V 1.8	R BANK UP DETECT CABLE
E3520721000	RF12AS	E9609729000A	ASM
EJECTOR VBH 07	Intelligent 16mm Tape Feeder	Mini Decompression Valve	E95587210A0
E3066700000	RF-Type (for RS-1)	PC0205010A0	RAIL SUPPORT
F EMERGENCY SW CABLE	RF16AS	MNLA	E2129729000B
ASM.	Intelligent 24mm Tape Feeder	E9611729000	RAIL SUPPORT C
E94107250A0	RF-Type (for RS-1) 40175380	MOTOR, THETA	E2330729000A
Feeder Bank Trunk Cable	RF24AS	E93067210A0	RAIL SUPPORT SHEET
E93877210A0	Intelligent 32mm Tape Feeder	NOZZLE 500 TIP 1.0 X 0.5	E2164729A00A
FEEDER UNIT PWB ASM	RF-Type (for RS-1)	(1005/1608)	RAIL SUPPORT SHEET
E86147150A0	RF32AS	E365X729000	E2164729C00B
FILTER (dia. 4.8mm id 2.9mm	Intelligent 44mm Tape Feeder	NOZZLE ASM 103	RAIL SUPPORT SHEET L
h 17.0mm)	RF-Type (for RS-1)	E35037210A0	40008097
E3052729000	RF44AS	Nozzle ASM for 0201	RAIL SUPPORT U
FILTER (dia. 5.0mm id 2.0mm	Intelligent 56mm Tape Feeder	E35017250A0	40008095
h 23.5mm)	RF-Type (for RS-1)	NOZZLE ASSEMBLY 514	REEL COLLAR 24mm PINK
40046646	RF56AS	E36197290A0	E6522705000
FILTER ELEMENT	Intelligent 8mm Tape Feeder	Nozzle Assy, # 102-Melf	REEL COLLAR 8 NF08NS

Juki SMT Machine Spares

E6378705000	NF-16	AQ02HP	40163249
RELAY	Tape feeder 16mm, Pitch adjustable (4/8/12)	Tape Feeder FTF 12mm standard, Pitch 4 - 12mm, 15" reel	VDS Display Monitor MIC-N952V-JK
HB000630000	NF-16NS	FF12FS	E94557150A0
ROTARY BLOCK ASSEMBLY	Tape feeder 24mm, Pitch adjustable (4/6/8/10)	Tape Feeder FTF 16mm standard, Pitch 4 - 12mm, 15" reel	VDS Display Monitor MJ-971Y7-JK 12V
E30107210A0	NF-24	FF16FS	39.591.023
SAFETY COVER STOPPER	Tape feeder 24mm, Pitch adjustable (6/8/10/12)	Tape Feeder FTF 24mm standard, Pitch 8 - 24mm, 15" reel	WAIT SENSOR CABLE A
E1348700000	NF-24FS	FF24FS	E94647250A0
Screw	Tape feeder 8mm Pitch (4), 7" reel	Tape Feeder FTF 32mm standard, Pitch 12 - 32mm, 15" reel	X AXIS CABLE BARE
SM8060502TP	NF-081E	FF32FS	E2429715000
SCREW SUPPORT	Tape feeder 8mm, Pitch adjustable (2/4), 15" reel	Tape Feeder FTF 44mm standard, Pitch 12 - 44mm, 15" reel	X AXIS PLASTIC RAIL ASM 20 with edge plates
E3004721000	NF-8LN	FF44FS	40008068
SENSOR MAGNET SWITCH	Tape feeder 8mm, Pitch adjustable (2/4), 7" reel	Tape Feeder FTF 44mm, deep pocket, pocket depth 25mm	X AXIS PLASTIC RAIL CHAIN 40 (21 links)
E9607715B00	NF-08N	FF56FS	40008069
SERVO MOTOR 30W Z AXIS	Tape Feeder ATF 16mm Deep Pocket 18mm Pocket Depth	Tape Feeder FTF 56mm standard, Pitch 12 - 16mm, 15" reel	X AXIS PLASTIC RAIL LINK 40
40044534	AF16FS-DP	FF564S	40008065
SET COLLAR	Tape Feeder ATF 24mm (Deep Pocket)	Tape Feeder FTF 56mm standard, Pitch 12 - 32mm, 15" reel	XY 4 SHAFT DRIVER(X SHAFT)
E3027721000	AF24FS-OP	FF568S	E9620729C00
SIGNAL TOWER (LIGHT BULB)	Tape Feeder ATF 24mm, 15" reel holder	Tape Feeder FTF 8mm paper (0402)	XY 4 SHAFT DRIVER(Y SHAFT)
E9690715000	AF24FS	FF08HE	E9620729D00
Stick feeder Lane No. 1-2, Comp.Types PLCC28/32, Lane Width .506"	Tape Feeder ATF 8mm paper (splicing) 0402 (1005), Pitch 2mm, 7" reel	Tape Feeder FTF 8mm, Pitch 4mm, 15" reel	Y - AXIS CABLE BEARER
MBF44-PLCC28/32	AF05HP	FF8L1E	E2331715000
Stick feeder Lane No.1, Comp.Types PLCC68, Lane Width 1.006"	Tape Feeder CTF 8mm embossed, Pitch 2mm, 7" reel	Tape Feeder FTF 8mm, Pitch 4mm, 7" reel	Y AXIS PLASTIC RAIL (40)
MBF44-PLCC68	CF08HE	FF081E	E2058729000
Stick feeder Lane No.1, Comp.Types PLCC84, Lane Width 1.206"	Tape Feeder CTF 8mm embossed, Pitch 4mm, 7" reel	Tape Feeder FTFR 32mm (Deep Pocket)	YA PULLLEY BRACKET ASM
MBF44-PLCC84	CF081E	FF32FR-OP	E23077210A0
Stick feeder Lane No.1-2, Comp.Typ.SOIC8-16 u.PLCC52, Lane Width.251" - .806"	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel	Tape Feeder FTFR 44mm (Deep Pocket)	Y-AXIS PLASTIC RAIL ASM (40) (only plastic rail)
MBF44-PLCC52/SOIC	CF08L1ER	FF44FR-OP	E2057729000
Stick feeder Lane No.1-2,Comp.Typ.SOL16-28 u.PLCC44, Lane Width.432" - .706"	Tape Feeder CTF 8mm embossed, Pitch 4mm, large reel	Tape Feeder FTFR 56mm	Y-AXIS PLASTIC RAIL ASM 20 (2010/2020 L)
MBF44-PLCC44/SOL	CF8L1E	FF56FR-OP	40017719
Stick feeder Lane No.1-2,Comp.Types PLCC20, Lane Width .404"	Tape Feeder CTF 8mm for 0201 and 0402 for 7" Reel	TAPE HOLDER 12 ASM	Z SLIDE BRACKET
MBF44-PLCC20	CF03HPR	E33107060A0A	E3007721000
Stick feeder Lane No.1-2,Comp.Types SOL16-28, Lane Width .432"	Tape Feeder CTF 8mm paper 0402 (1005), Pitch 2mm, 7" reel	THETA COUPLING	Z SLIDER SHAFT
MBF44-SOL	CF05HP	E3025725000	E3008721000
Stick feeder Lane No.1-4, Comp.Types SOIC 8-16, Lane Width .251"	Tape Feeder CTF 8mm paper, Pitch 4mm, large reel	THETA PULLEY	Z-SLIDE SHAFT A
MBF44-SOIC	CF8L1P	E3011721000	E30067250A0
SWING PLATE ASM	Tape Feeder CTFR 8mm Pitch 4mm	UNION FILTER	Z-SLIDE SHAFT IC ASM
E11067060A0A	CF8L1ER	PF010001000	E32
T BELT TENSIONER	Tape Feeder for 01005 1.115	UPPER COVER 1212 ASM	BEARING
E3012721000		E32037060AC	SB304000100
Tape feeder 12mm, Pitch adjustable (4/8/12)		UPPER COVER ASM for CF081E CF8L1E FF081E and FF8L1E	CLUTCH HOLDER ASM.
NF-12		E2203706CA0	E1301706AA0
Tape feeder 12mm, Pitch adjustable (4/8/12)		Vacuum Filter RX-7	HOLDER_PLATE_ASM CTFR 40081848
NF-12NS			HOLDER_SH CTFR 40081849
Tape feeder 16mm, Pitch adjustable (4/8/12)			HOUSING ASM

Juki SMT Machine Spares

REEL SUPPORT ARM ASM. E1610706AA0 SHAFT E1314706A00	E1005-706-CA0 X-AXIS POSITIONING PIN E1002-706-000	E3203-706-0AB UPPER COVER 1212 ASM . E3203-706-0AC UPPER COVER 1604 ASM
SHAKE ARM (CTFR) 40081807 SHAKE ARM 4MM ASM 40081827	12/16/24MM FEEDER E3292-760-000 BEARING SB304000100	E4203-706-0AA UPPER COVER 1608 ASM (2) E4203-706-0AB UPPER COVER 1612 ASM .
SHAKE ARM ASM E1303-706-0A0 SHAKE ARM ASM) E1303706AC0 SLIDE PLATE (ATF8mm) E1115-706-A00	LINK 24ASM E5115-706-0B0 LINK 24ASM (FF24mm) E5115-706-0B0 LINK ASM E3115-706-0B0	E4203-706-0AC UPPER COVER 2408 ASM E5203-706-00A UPPER COVER 2412 ASM (3). E5203-706-0AB UPPER COVER 2416 ASM
STOPPER CLICK 40081800 STOPPER HOOK E1112-706-C0 STOPPER HOOK E1112-706-000-A	LINK ASM. E11157060B0 LOCK HOLDER SCREW E1523-706-C00 OUT PUT GUIDE E7402706000	E5203-706-0AC UPPER COVER 2424 ASM E5203-706-0AD UPPER COVER 3212ST E6203706RB0 UPPER COVER 3232ASM
SWING PLATE 03 ASM.) E1106706CB0 SWING PLATE ASM E1106-706-0A0 TAPE HOLDER ASM. E1310706CA0	Pressure roller asm (ATF8mm) E1321-706-AA0 REEL HOUSING ASM E1304-706-0B0 REEL SHAFT E3306-706-000	E6203-706-0AC UPPER COVER 4444ASM E7203-706-0AC UPPER COVER SHAFT E1209-706-000 WHEEL ASM (Sprocket) E1102-706-0A0
TAPE HOLDER PLATE E1321706C00 TAPE HOLDER_ASM (CTFR) 40081851 UP CV 08 ASM □ CTFR □ 40081845 UP CV HOOK ASM 40081910	REEL SHAFT E3306-706-000 JM REEL SHAFT (CTF) E1307-706-C00 REEL SHAFT 32R 1 E6666706R00 SHAKE ARM ASM E1303-706-0A0	UPPER COVER 2424 ASM E1209-706-000 WHEEL ASM (Sprocket) E1102-706-0A0 X-AXIS POSITIONING PIN ASM (FTF) E1001-706-0A0-A
UPPER COVER 05 ASM (ATF) E1201-706-AA0 UPPER COVER 08ASM E1202-706-AA0 UPPER COVER 1212 ASM. E3203706AACA UPPER COVER 1612 ASM. E4203706AACA UPPER COVER 2424 ASM. E5203706AAE	SHUTTER PLATE 32 ASM. E62207060A0 ST PL BK 1 E6125706R00 STOPPER 12/16/24-NS E313070600E STOPPER 8×2) E6822-705-000 STOPPER HOOK E1112-706-000-A	
UPPER COVER ASM(3). E1202-706-CA0 UPPER COVER ASM(5). E1203-706-CA0 UPPER COVER HOOK E1211-706-C00-A UPPER COVER SHAFT E1209-706-000 UPPER COVER SHAFT (CTF) E1209-706-C00	SUTTER PLATE 32 ASM. 1 E6220706AA0 SWING PLATE ASM E3106-706-0A0 SWING PLATE ASM. E61067060A0 TAPE HOLDER ASM (CTF) E1310-706-CA0 TAPE HOLDER ASM. E6310-706-0A0-A TAPE HOLDER ASM. E3310-706-0A0 TAPE HOLDER ASM. (FTF44mmmm) E7310-706-0A0-A UPPER COVER 08 ASM. E2203-706-CA0 UPPER COVER 1204 ASM E3203-706-0AA UPPER COVER 1208 ASM	
WHEEL ASM (Sprocket) E1102-706-0A0 WHEEL BUSH SPACER 03 E1108706C00 WHEEL COLLAR 03 E1104706C00 WHEEL PLATE 03 E1130706C00 WHEEL RING 03 E1109706C00 X-Axis adjusting bracket asm. (CTF/ATF)		