

**SPECTRUMSMT.COM**  
info@spectrumsmt.com



Call USA: +1 (855) 261 1805  
Call UK: +44 0844 556 1203

**US • UK • EU**

# SMT MACHINE SPARES

---

## Panasonic SMT Machine Spares

### Part numbers and descriptions

Working with our partners worldwide we have access to a large inventory of original machine spares for both current and older machines. In many cases we have stock of obsolete parts for machines no longer supported by the manufacturer. For your convenience we have listed, in an easy to read format, the spares offered by the manufacturers. We also repair and exchange many spares parts.

If you cannot locate what you need from your main dealer or you are interested in making some savings then please feel free to contact us for a quote and availability.

---

## YOUR PERFECT SMT PARTNER

## Panasonic SMT Machine Spares

NOZZLE 1001  
KXFW1ASAA00

NOZZLE 1002  
KXFW1ATAA00

NOZZLE 1003  
KXFW10YAA00  
KXFX037UA00

NOZZLE 1004  
KXFW1AUAA00

NOZZLE 1005  
KXFW1AVAA00

NOZZLE 1006  
KXFX03DUA00  
KXFX037XA00

NOZZLE 110  
KXFX04MSA00

NOZZLE 115  
KXFX04MTA00

NOZZLE 120  
KXFX04MUA00

NOZZLE 130  
KXFX04MVA00

NOZZLE 140  
KXFX04MXA00

NOZZLE 450  
KXFX04MZA00

NOZZLE 205  
KXFX04NOA00

NOZZLE 460  
KXFX03NGA00

NOZZLE 206A  
KXFX05V2A00

NOZZLE 225C  
N610040782AA

NOZZLE 226C  
N610040783AA

NOZZLE 230C  
N610040784AA

NOZZLE 235C  
N610043814AA

NOZZLE 240C  
N610062681AA

NOZZLE 230CS  
N610040788AA

NOZZLE 235CS  
N610043815AA

NOZZLE 225CS  
N610040786AA

NOZZLE 240CS  
N610040853AD

NOZZLE 110S  
N610017371AC

NOZZLE 120S  
N610017373AC

NOZZLE 115AS  
N610017372AS

NOZZLE 130S  
N610017375AD

NOZZLE 185  
N610070338AB

NOZZLE 205  
N610000995AA  
KXFX04NOA00

NOZZLE 205S  
N610017370AS

NOZZLE 206  
N610099782AA

NOZZLE 226C  
N610040783AC

NOZZLE 226CS  
N610040787AD

NOZZLE 1518  
KXFX05GHA00

NOZZLE 1528  
KXFX05GZA00

NOZZLE 1514  
KXFX05G9A00

NOZZLE 1604  
KXFX05L9A00

NOZZLE 1580  
KXFX05KRA00

NOZZLE 1479  
KXFX05ASA00

NOZZLE 1403  
KXFX0556A00

NOZZLE 1191  
KXFX04U4A00

NOZZLE 1272  
KXFX04YKA00

NOZZLE 1118  
KXFX04PQA00

NOZZLE 1101  
KXFX04NBA00

NOZZLE 1248  
KXFX04X8A00

NOZZLE 1112  
KXFX04PCA00

NOZZLE 1229  
KXFX04W6A00

NOZZLE 2405  
KXFX05BVA00

NOZZLE 1192  
KXFX04U6A00

NOZZLE 1252  
KXFX04XEA00

NOZZLE 1180  
KXFX04TGA00

NOZZLE 1202  
KXFX04UQA00

NOZZLE 1109  
KXFX04P6A00

NOZZLE 1128  
KXFX04QAA00

NOZZLE 1656  
KXFX05MXA00

NOZZLE 1249  
KXFX04XAA00

NOZZLE 1333  
KXFX051JA00

NOZZLE 1404  
KXFX0558A00

NOZZLE 1115  
KXFX04PJA00

NOZZLE 1173  
KXFX04T0A00

NOZZLE 1105  
KXFX04NXA00

NOZZLE 2437  
KXFX05DRA00

NOZZLE 1421  
KXFX056AA00

NOZZLE 1137  
KXFX04QUA00

NOZZLE 1148  
KXFX04RJA00

NOZZLE 1237  
KXFX04WNA00

NOZZLE 206AS  
N610030510AC

NOZZLE 2418  
KXFX05CMA00

NOZZLE 1006N  
N610114702AA

NOZZLE 110N  
N610099372AA  
KXFX0MSA00

NOZZLE 115ASN  
N610017372AA  
N610071372AC

NOZZLE 182  
N610055943AA

NOZZLE 226CSN  
N610119480AB

NOZZLE 235CN  
N610119496AA

NOZZLE 240CN  
N610119499AB

NOZZLE 240CSN  
N610119486AB

NOZZLE 256CSN  
N610136384AA

NOZZLE 230CN  
N610119493AB

NOZZLE 199  
N610070079AB

NOZZLE 161S  
N610058431AA

NOZZLE 1001N  
N610098969AA

NOZZLE 1002N  
N610098970AA

NOZZLE 1003N  
N610098971AA

NOZZLE 1004N  
N610098972AA

NOZZLE 1005N  
N610098973AA

## Panasonic SMT Machine Spares

NOZZLE 161SN N610126849AA	ARM KXFB00HMA02	VALVE N510028350AA	KXF0DSSAA00
NOZZLE 230CSN N610119484AB	BALL SPLINE N510002505AA	VALVE KXF0A1RAA00	SENSOR KXF0DL2AA01
NOZZLE 235CSN N610119485AB	HOLDER KXFB02M2A01	VALVE KXF0A3RAA00	SENSOR N610006577AA
NOZZLE 140N N610099376AA	CLAMP ARM KXFB00S6A03	VALVE N510063837AA	SENSOR KXF0DKZAA00
NOZZLE 184N N610126914AA	BEARING KXF02G7AA00	VALVE KXF0DLLAA01	SENSOR KXF0DL0AA01
NOZZLE 185N N610119411AA	SPRING N210007425AA	VALVE KXF0DLKAA01	SENSOR KXF0DH4AA01
NOZZLE 161 N610058431AA	SPRING KXF0DKAAA00 KXF0DAAA00	Z Axis Motor N510043454AA	SENSOR N610017022AD
NOZZLE 120N N610099374AA	BEARING KXF0CSVAA00	Z Axis Motor N510043456AA	SENSOR N610017023AC
NOZZLE 130N N610099375AA	BELT N510030308AA	MOTOR KXF0CWLAA00	SENSOR N510025620AA
FILTER N610071334AA	BALL SPLINE N510028739AA	MOTOR KXF0E1LXA00	SENSOR N510037016AB
AIR FILTER KXF0E3RRA00	Z Axis Motor N510042737AA N510030833AB	MOTOR N510048981AA	SENSOR N510068527AA
FILTER N510068213AA	Z Axis Motor N510042738AA	MOTOR N510005279AA	SENSOR N510068525AA
FILTER N510059196AA	Z Axis Motor N510042739AA	MOTOR KXF0DX1BA00	SENSOR N510068517AA
FILTER N510059928AA	Z Axis Motor N510042740AA KXF0DGEEA00	MOTOR N510057033AA	SENSOR N510068515AA
FILTER N610009394AA	50W Motor KXF0DHSAA00	MOTOR N510048142AA	SENSOR N510037015AB
FITER N610097899AA	50W Motor N510008188AA	MOTOR N510043555AA	SENSOR N510068516AA
HOLDER N210017657AB	Track motor N510048981AA	MOTOR N510022126AA	SENSOR N510068524AA
CLAMP KXFB00L1A02	CABLE-BEAR N510002655AA	MOTOR N510056943AA N510044462AA	BALL SPLINE KXF0DTQAA01
BEARING KXF0AL1AA00	VALVE KXF0DX8NA00	SENSOR N610027221AA	MO-DRIVER KXFP6GB0A00
BALL SPLINE N510015534AA	VALVE N510054843AA	SENSOR N610026749AA	MO-DRIVER KXFP6GE1A00
TUBE KXF0DS4AA00	VALVE N510063838AA	SENSOR N610013591AA	MO-DRIVER N510002593AA
SPRING N210076717AA	VALVE KXF09X3AA00	SENSOR N610002222AA	MO-DRIVER N510002594AA
		SENSOR	CYLINDER KXF0DXM1A00

## Panasonic SMT Machine Spares

CYLINDER KXF0DY80A00	CABLE W/CONNECT N510026218AA	BELT 110HC181222	Tape Feeder, 72mm, Splicing sensing, TypeA KXFW1KS9A00
CABLE W/CONNECT N510053281AA	CABLE W/CONNECT N510026219AA	BELT 180GC182093	Tape Feeder, 72mm, TypeA KXFW1KSFA00
CABLE W/CONNECT N510026292AA	CABLE W/CONNECT N510055991AA	BELT 030CC181371	PRESSER-COVER N610002833AA
CABLE W/CONNECT “N510026293AA “	CABLE W/CONNECT N510055992AA	BELT 030CC181451	TENSIONER N610025477AB
CABLE W/CONNECT N510026294AA	BELT KXF0DKCAA00	BELT N510030980AA	TENSIONER N610007640AB
CABLE W/CONNECT N510026295AA	BELT KXF0DKCAA00	BELT N510060976AA	LEVER N610025484AA
CABLE W/CONNECT N510026318AA	BELT KXF0DKDAA00	BELT N510063692AA	LEVER N610025485AA
CABLE W/CONNECT N510026319AA	BELT KXF0DKFAA00	BELT N510060975AA	COVER KXFA1MLAA00
CABLE W/CONNECT N510026320AA	BELT KXF0DKCAA00	Tape Feeder 8mm Double Splicing sensing TypeA KXFW1KS5A00	MAGNET KXF0DYAZA00
CABLE W/CONNECT N510026321AA	BELT KXF0DKGAA00	Tape Feeder 8mm Double TypeA KXFW1KSBA00	SCREW XXE25C3FP
CABLE W/CONNECT N510026380AA	BELT N510022408AA	Tape Feeder 8mm Single Splicing sensing TypeA N610003476AA	COVER N210005449AA
CABLE W/CONNECT N510026375AA	BELT N510019317AA	Tape Feeder 8mm Single TypeA N610003478AA	SPRING KXF0DWTGA01
CABLE W/CONNECT N510026368AA	BELT N510004586AA	Tape Feeder, 12, 16mm, Splicing sensing, TypeA KXFW1KS6A00	PIN KXFA1PQ3A00
CABLE W/CONNECT N510026366AA	BELT N510027770AA	Tape Feeder, 12, 16mm, TypeA KXFW1KSCA00	SPRING KXF0DK1AA00
CABLE W/CONNECT N510026367AA	BELT N510019318AA	Tape Feeder, 24, 32mm, Splicing sensing, TypeA KXFW1KS7A00	GEAR N210047118AB
CABLE W/CONNECT N610054141AA	BELT KXF0DWTDB00	Tape Feeder, 24, 32mm, TypeA KXFW1KSDA00	PIN KXFA1KPAA00
CABLE W/CONNECT N510026397AA	BELT KXF0E0T9A01	Tape Feeder, 44, 56mm, Splicing sensing, TypeA KXFW1KS8A00	PIN KXFA1KQAA00
CABLE W/CONNECT N510026398AA	BELT KXF0E0R1A00	Tape Feeder, 44, 56mm, Splicing sensing, TypeA KXFW1KSEA00	COMB KXFA1PSSA00
CABLE W/CONNECT N510026399AA	BELT KXF07UWAA00	Tape Feeder, 44, 56mm, Splicing sensing, TypeA KXFW1KS8A00	SCREW XSS3+6VW
CABLE W/CONNECT N510026400AA	BELT KXF0DXDTA00	Tape Feeder, 44, 56mm, Splicing sensing, TypeA KXFW1KS8A00	SCREW N510002400AA
CABLE W/CONNECT N510026215AA	BELT KXF0DXDUA00	Tape Feeder, 44, 56mm, TypeA KXFW1KSEA00	PIN KXFA1KFAA00
CABLE W/CONNECT N510026217AA	BELT KXF0DWXZB01		ROLLER KXFA1KHBA00

## Panasonic SMT Machine Spares

SPRING KXF0DK4AB00	BOLT XVE3B8FYA	PIN KXFA1KRAA00	PRESSER-COVER N610011373AA
PIN N210045625AA	WASHER XWG3FY	LEVER N210029789AA	SLIT-PLATE N610001649AA
LEVER KXFA1MJAA00	PLATE N610014970AE	PIN KXFA1LJAA00	TENSIONER N610025479AB
LEVER KXFA1MKAA00	COVER KXFA1MPBA01	PIN KXFA1LEAA00	COVER KXFA1NLAA00
WASHER KXF0B88AA00	COVER KXFA1MQBA01	ROLLER KXFA1LDAA00	MAGNET KXF0DYAZA00
BOLT XVE4B8FYA	PRESSER-COVER N610002834AB	SPRING KXF0DK6AA00 SP(DA KXF0DK6AA00)	SCREW XXE25C3FP
CLICK KXFW1KWJA00	SLIT-PLATE N610001648AA	GEAR N210050454AA	COVER N210020703AA
CLICK N610007636AA	TENSIONER N610025478AB	LEVER KXFA1N4AA00	COVER KXFA1PR5B01
COMB KXFA1PSTA01	COVER KXFA1N5AA00	CLICK KXFW1KWA00	GUIDE N210006456AA
COMB KXFA1PSUA01	MAGNET KXF0DYAZA00	TAPE-GUIDE KXFW1KXJA00	PIN KXFA1PQ5B00
SCREW XSN25+3VW	SCREW XXE25C3FP	COMB KXFA1PSYA02	PIN KXFA1LHAA00
PIN KXFA1PS9A00	COVER KXFA1N0AA02	SCREW N510002400AA	GUIDE KXFA1NNAA00
PIN KXFA1L0AA00	GUIDE N210006455AA	GEAR N210050453AA	SCREW KXF0DYAJA00
PIN KXFA1KAAA00	PIN KXFA1PQ5B00	CLICK KXFA1PT7A00	SPRING KXF0DYUFA01
PIN KXFA1KBAA00	GUIDE KXFA1NBAA00	GUIDE KXFA1PT9A01	SCREW XSN25+6VW
CLICK KXFA1PT4A00	SCREW KXF0DYAJA00 SO20659-2001(DAA)	SCREW XSN25+6VM	GEAR N210050456AA
CLICK KXFA1PT5A00	SPRING KXF0DYUFA01 SP(DA KXF0DYUFA01)	COVER KXFA1N6BA00	PIN KXFA1LSAA00
SPRING KXF0DRSAA00	PIN KXFA1LGAA00	SCREW XSS25+6VM	PIN N210044529AA
PLATE KXFA1PZHB01	PIN N210044529AA	SCREW XSN25+6VM	COMB KXFA1PT0A00
SCREW XSN25+4VW	COMB KXFA1PSXA00	PLATE KXFA1PZJB01	SCREW N510002400AA
SCREW XSN25+3VW	SCREW N510002400AA	SCREW XSN25+4VW	LEVER N210029790AA
BLOCK N210014414AA		SCREW XSS25+6VW	PIN KXFA1LTAA00

## Panasonic SMT Machine Spares

PIN KXFA1LQAA00	PRESSER-COVER N610011374AA	PIN KXFA1M3AA00	PRESSER-COVER N610011375AA
LEVER N210038151AA	TENSIONER N610025480AB	PIN KXFA1LZAA00	TENSIONER N610025481AB
ROLLER KXFA1LPBA00	PN KXFA1M2AA00	ROLLER KXFA1LYAA00	PIN KXFA1M9AA00
SPRING KXF0DK6AA00	COVER KXFA1P1AA00	SPRING KXF0DK6AA00	COVER KXFA1PBAA00
LEVER KXFA1NKAA00	MAGNET KXF0DYAZA00	LEVER KXFA1P0AA00	MAGNET KXF0DYAZA00
LEVER KXFA1NSAA00	SCREW XXE25C3FP	LEVER KXFA1NSAA00	SCREW XXE25C3FP
CLICK KXFW1KWLA00	COVER N210020703AA	COMB KXFA1PR8B00	COVER N210020703AA
TAPE-GUIDE KXFW1KXLA00	COVER KXFA1PR5B01	CLICK KXFW1KWMA00	COVER KXFA1PR5B01
COMB KXFA1PT1A02	GUIDE N210006457AA	TAPE-GUIDE KXFW1KXLA00	GUIDE N210006458AA
SCREW N510002400AA	PIN KXFA1PQ5B00	COMB KXFA1PR8B00	PIN KXFA1PQ5B00
GEAR N210050455AA	GUIDE N210005457AA	GEAR KXFA1PQ7A02	GUIDE N210005458AA
PIN KXFA1LSAA00	GUIDE KXFA1P3AA00	BUSH KXF0CWGAA00	GUIDE KXFA1PDAA00
SCREW XSN25+6VW	SCREW KXF0DYAJA00	PIN KXFA1M1AA00	SCREW KXF0DYAJA00
CLICK KXFA1PTAA00	PIN KXFA1Q0LA00	SCREW XSN25+6VW	SPRING KXF0DK1AA00
GUIDE KXFA1PTDA01	PLATE KXFA1Q0PA00	CLICK KXFA1PTEA00	SCREW XSN25+6VW
SCREW XSN25+6VW	SPRING KXF0DK1AA00	SPRING KXF0DRSA00	BUSH KXF0CWGAA00
COVER KXFA1N8BA01	SCREW XSN25+6VW	GUIDE KXFA1PTGA00	PIN N210044529AA
SCREW XSN25+6VW	BUSH KXF0CWGAA00	SCREW XSN25+6VW	PIN KXFA1M8AA00
SCREW XSN25+4VW	PIN N210044529AA	PLATE KXFA1PZLB02	GEAR KXFA1PQ8A02
PLATE KXFA1PZKB01	PIN KXFA1M1AA00	SCREW XSN25+4VW	COMB KXFA1PS1B00
BRACKET KXFA1NTAA00	GEAR KXFA1PQ7A02	BRACKET KXFA1NTAA00	LEVER N210029790AA
GUIDE N210005463AB	LEVER N210029790AA	GUIDE N210005464AB	PIN KXFA1MAAA00

## Panasonic SMT Machine Spares

PIN KXFA1M6AA00	BOARD N610106340AA N610065254AB	BOARD N510036830AA KXFP5XHAA00
ROLLER KXFA1M5AA00		BOARD N610102506AA N610063474AB
SPRING KXF0DK6AA00	BOARD N610169311AA	
LEVER KXFA1PAAA00	BOARD KXFE00FKA00	BOARD N610084745AA N610017723AA N610017723AC
LEVER KXFA1NSAA00	BOARD MTKB000085AA	BOARD N610106341AA
CLICK KXFW1KWNA00	Board N610051792AA	BOARD N610110715AA
TAPE-GUIDE KXFW1KXLA00	Board N610120633AA	BOARD N610140450AA
COMB KXFA1PS2B00	BOARD N610030275AA	BOARD N610106335AB N610106335AA
GEAR KXFA1PQ8A02	BOARD N610001129AA	BOARD MTKB000146AA
BUSH KXF0CWGAA00	BOARD KXFE0002A00	PIN,STAINLESS STEEL N610133066AA
PIN KXFA1M8AA00	BOARD N610108741AA KXFE000HA00 N610012673AA	PIN,STAINLESS STEEL N610087389AA
SCREW XSN25+6VW	BOARD KXFE0001A00	BOARD N610012674AA
CLICK KXFA1PTHA00	BOARD N610090171AA	CAMERA N510002507AA
SCREW XSN25+6VW	KXFE0005A00 KXFE00GXA00	CABLE W/ CONNECTOR,500V CU KXFP6ELLA00
PLATE KXFA1PZMB02	BOARD KXFE000EA00	GUIDE,POLYACETAL N210040138AA N210040576AA
SCREW XSN25+4VW	BOARD KXFE00F0A00	NUT KXFB019FA00
BRACKET KXFA1NTAA00	BOARD N610102225AA	SEAL KXF0DWTLA00
BOARD N610154418AA N610119965AA	BOARD KXFE0004A00	SEAL KXF0DWTKA00
BOARD N610145898AA	BOARD N610113311AA	PIN,STAINLESS STEEL
Board N610120952AA	BOARD N610079679AA	
Board N610164162AA	BOARD N610013410AC N610013410AA	
	BOARD KXFE0008A00	